




42" MOWER



Ref #	Part Number	Qty	Description
52	105529X		SUB= 139888
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	133844		IDLER ARM
56	122052X		SPACER RETAINER
57	127498		BUSHING
58	128759		SUB= 918128759
59	138003		LEVER.ASM.CLUTCH
60	134666		"ROD, CLUTCH PRIM"
61	131870		RETURN SPRING
62	127847		CLUTCH ARM SECOND
63	121748X		WASHER
64	12000029		RING
65	128903		SHOULDER BOLT
66	127845		SPRING KEEPER
67	132044		SUB= 532132044
68	130969		BELT-V.92.4.MWR
	138357		SUB= 145411
	130794		MANDREL ASM



42" MOWER




Ref #	Part Number	Qty	Description
1	138024		SUB= 145338
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
4A	132827		BOLT SHD 5/16-18
5	4939M		SUB= 85902
6	130832		SUB= 130833
7	73800500		NUT
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	129962		WASHER BLADE
11	138498		"BLADE.42"" HIPERF"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	136929		SUB= 140329
17	72110618		BOLT CARRIAGE
18	72140505		BOLT
19	73800500		NUT
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	78158		SUB= 17580520
31	129963		WASHER
32	129861		SUB= 153535
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131612		WASHER GT
38	133502		RETAINER SPACER
39	133503		IDLER ARM STIFF
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
42	76020312		SUB= 3145
43	133504		CLUTCH ROD SECOND
44	134236		SUB= 140088
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
47	131335		SPRING EXTENSION
48	133944		HARD SMALL WASHER
49	133940		SUB= 151785
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	105529X		SUB= 139888
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	133844		IDLER ARM
56	122052X		SPACER RETAINER
57	127498		BUSHING

Ref #	Part Number	Qty	Description
58	128759		SUB= 918128759
59	138003		LEVER.ASM.CLUTCH
60	134666		"ROD, CLUTCH PRIM"
61	131870		RETURN SPRING
62	127847		CLUTCH ARM SECOND
63	121748X		WASHER
64	12000029		RING
65	128903		SHOULDER BOLT
66	127845		SPRING KEEPER
67	132044		SUB= 532132044
68	130969		BELT-V.92.4.MWR
	138357		SUB= 145411
	130794		MANDREL ASM




DECALS



Ref #	Part Number	Qty	Description
1	136832		DECAL
3	135326		NLA
4	135325		NLA
7	133796		DECAL
8	4900J		DECAL T
9	134216		NLA
11	135329		DECAL
15	138955		DECAL.DASH.INST.
18	135328		NLA
	138311		DECAL HANDLE LIFT
	139948		MANUAL.O.JP1442C
	C42		GRASS CATCHER
	BD20		42" SNOW BLOWER
	SB20		40" SNOW THROWER




DRIVE




Ref #	Part Number	Qty	Description
1	137369		SUB= 137367
2	110422X		SUB= 146682
3	123667X		"PULLEY,TRANSAXLE"
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
7	130802		SUB= 162240
8	131679		SHIFT ROD
9	19151216		WASHER
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
12	19091210		WASHER LT
13	71040412		SUB= 74550412
14	10040400		LOCKWASHER
15	74786054		BOLT
16	73680500		SUB= 73690500
17	121520X		STRAP TORQUE
18	74760612		SUB= 74780612
19	73680600		SUB= 73690600
20	17490512		SCREW
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
23	73800600		NUT
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	133261		BRAKE PARK ROD
29	71673		PLUNGER CAP T
30	130807		TRANSAXLE MTG BKT
31	127289		"KEEPER,BELT LH"
32	74760512		BOLT
33	73680500		SUB= 73690500
34	122424X		SUB= 149001
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
43	73680600		SUB= 73690600
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	19131316		WASHER
53	105710X		"LINK, CLUTCH T"
54	76020412		COTTER PIN
55	105709X		"SPRING, RETURN LT"
56	76020412		COTTER PIN
57	131006		BELT-V
58	127290		"KEEPER,BELT RH"

Ref #	Part Number	Qty	Description
59	136715		SUB= 140312
60	19131312		WASHER
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	134825		SUB= 136004
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129921		KEEPER.BELT.ENG.L
67	74760616		BOLT
68	19131312		WASHER
69	73680600		SUB= 73690600
70	134683		KEEPER BELT ENG
71	74760616		BOLT
72	19132012		WASHER
73	73680600		SUB= 73690600
74	109502X		SPACER LT
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
79	19111216		WASHER M
94	17490616		SCREW GTV
95	135029		MUFFLER GUARD
96	2751R		CLIP T
97	72110608		BOLT D
98	19131616		WASHER HYT




DRIVE










Ref #	Part Number	Qty	Description
1	137369		SUB= 137367
2	110422X		SUB= 146682
3	123667X		"PULLEY,TRANSAXLE"
4	12000028		SUB= 2267J
5	121520X		STRAP TORQUE
6	17490512		SCREW
7	130802		SUB= 162240
8	131679		SHIFT ROD
9	19151216		WASHER
10	76020416		PIN COTTER 1/8
11	105701X		WASH-SHFT PLT LT
12	19091210		WASHER LT
13	71040412		SUB= 74550412
14	10040400		LOCKWASHER
15	74786054		BOLT
16	73680500		SUB= 73690500
17	121520X		STRAP TORQUE
18	74760612		SUB= 74780612
19	73680600		SUB= 73690600
20	17490512		SCREW
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
23	73800600		NUT
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	133261		BRAKE PARK ROD
29	71673		PLUNGER CAP T
30	130807		TRANSAXLE MTG BKT
31	127289		"KEEPER,BELT LH"
32	74760512		BOLT
33	73680500		SUB= 73690500
34	122424X		SUB= 149001
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	109070X		BELT KEEPER LT
42	19131312		WASHER
43	73680600		SUB= 73690600
44	105706X		"LY, BEARING"
45	110812X		WASHER LT
46	12000039		KLIP RING
47	127783		SUB= 139245
48	123789X		ARM IDLER
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	19131316		WASHER
53	105710X		"LINK, CLUTCH T"
54	76020412		COTTER PIN
55	105709X		"SPRING, RETURN LT"
56	76020412		COTTER PIN
57	131006		BELT-V
58	127290		"KEEPER,BELT RH"

Ref #	Part Number	Qty	Description
59	136715		SUB= 140312
60	19131312		WASHER
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	134825		SUB= 136004
64	71170764		BOLT
65	10040700		LOCKWASHER
66	129921		KEEPER.BELT.ENG.L
67	74760616		BOLT
68	19131312		WASHER
69	73680600		SUB= 73690600
70	134683		KEEPER BELT ENG
71	74760616		BOLT
72	19132012		WASHER
73	73680600		SUB= 73690600
74	109502X		SPACER LT
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
79	19111216		WASHER M
94	17490616		SCREW GTV
95	135029		MUFFLER GUARD
96	2751R		CLIP T
97	72110608		BOLT D
98	19131616		WASHER HYT




ELECTRICAL

- | | | |
|---|---|---|
| A | B | C |
|  47 |  41 |  28 |
| |  27 |  32 |
| | |  29 |




Ref #	Part Number	Qty	Description
1	123198X		SUB= 146525
2	19091016		WASHER
3	102476X		SUB= 150109
4	72240460		BOLT
5			REFER TO IMAGE
6	7603J		"TRAY T, BATTERY"
7	138816		HARNESS.IGN. B&S
8	136849		SUB= 136850
9	7662J		SUB= 4152J
10	7697J		"DRAIN TU T, BATT"
11	7192J		WIRE TIE
12	109553X		SWITCH INTERLOCKT
13	4206J		CABLE-BATTERY T
14	4406R		SUB= STD365402
15	124211X		NUT IGNITION
16	122147X		KEY
17	138406		SUB= 146154
18	110712X		SWITCH LT
21	4799J		"CABLE T, BATTERY"
22	131563		SUB= 154336
23	4207J		CABLE T
25	109596X		HOSE CLAMP T
26	10040400		LOCKWASHER
27	73350400		NUT
28	74780408		BOLT
29	73510400		NUT
30	74760412		BOLT LT
31	73220400		SUB= 50675
32	11050400		LOCKWASHER
33	108824X		FUSE HYT
41	10090400		SUB= 10040400
42	104445X		SWITCH-INTER. GT
45	123620X		SUB= 141226
46	121305X		SWITCH SEAT
47	17021008		SCREW
48	19121618		WASHER.3/4X1X18GA
49	108236X		BRACKET LT
50	130890		SWITCH BRACKET
51	11150400		LOCKWASHER

ENCLOSURES




Ref #	Part Number	Qty	Description
1	10040400		LOCKWASHER
2	11050600		LOCKWASHER
3	132638X473		"PANEL,SIDE LH "
4	135138X016		PLATE.DASH
5	124252X		SUB= 140398
6	132177		LOWER DASH
7	73510400		NUT
8	137654		SUB= 140181
9	124130X		SUPPORT ASSY
12	106784X		SUB= 155013
13	104618X		SUB= 155013
14	132635X473		HOOD
15	124392X417		SUB= 147717
16	106395X		LENS LT
18	122100X		GRILL ASSY
19	105419X473		"STRAP,GRILL"
22	136337X473		"PANEL,SIDE RH"
23	132069		SUB= 532132069
24	105475X473		FOOTREST RH
25	135034		SUB= 145501
26	137275		SUB= 145009
27	132178		DASH PANEL LH
28	105476X473		FOOTREST LH
30	131343X037		SADDLE. 6SP
31	19091216		WASHER PM
37	109872X473		FENDER
40	73220400		SUB= 50675
41	74760612		SUB= 74780612
42	19131312		WASHER
43	73680600		SUB= 73690600
45	17211010		SCREW LT
46	104755X		"J" FASTENER LT"
47	17490612		SCREW
48	17490512		SCREW
49	123481X		SUB= 7605J
50	73680400		SUB= 73690400
53	17490608		SCREW LT
56	74780512		BOLT
57	73510500		NUT
58	136619		BRKT FENDER
59	74180512		SCREW
60	73680500		SUB= 73690500
61	19131210		WASHER
65	72110606		BOLT
67	74191008		SCREW
68	10071000		LOCKWASHER
69	2029J		WELDNUT
70	109808X		HOOD LATCH T
71	74981020		SCREW
72	7206J		SPACER LT
73	73731000		NUT
77	19070818		WASHER
79	2751R		CLIP T
84	19111116		WASHER
90	136462		"BAFFLE,VERTICLE"
95	123198X		SUB= 146525
99	109458X		FOAM STRIP T
100	126471X		"CLIP,INSULATOR"

Ref #	Part Number	Qty	Description
101	110852X		SUPPORT LH YTH
102	110853X		SUPPORT RH YTH
105	132644		SUB= 532132644
107	134774		PIVOT BRKT LH
108	134775		PIVOT BRKT RH
109	72140608		SUB= 72110608
112	110855X		SUPPORT LH YTH
113	110854X		SUPPORT RH YTH
114	17490412		SCREW HEX CRT
115	19091016		WASHER
116	19111212		WASHER
117	74760616		BOLT
118	73800600		NUT
119	72140608		SUB= 72110608
120	74760614		SUB= 74760616




Ref #	Part Number	Qty	Description
1	10040400		LOCKWASHER
2	11050600		LOCKWASHER
3	132638X473		"PANEL,SIDE LH "
4	135138X016		PLATE.DASH
5	124252X		SUB= 140398
6	132177		LOWER DASH
7	73510400		NUT
8	137654		SUB= 140181
9	124130X		SUPPORT ASSY
12	106784X		SUB= 155013
13	104618X		SUB= 155013
14	132635X473		HOOD
15	124392X417		SUB= 147717
16	106395X		LENS LT
18	122100X		GRILL ASSY
19	105419X473		"STRAP,GRILL"
22	136337X473		"PANEL,SIDE RH"
23	132069		SUB= 532132069
24	105475X473		FOOTREST RH
25	135034		SUB= 145501
26	137275		SUB= 145009
27	132178		DASH PANEL LH
28	105476X473		FOOTREST LH
30	131343X037		SADDLE. 6SP
31	19091216		WASHER PM
37	109872X473		FENDER
40	73220400		SUB= 50675
41	74760612		SUB= 74780612
42	19131312		WASHER
43	73680600		SUB= 73690600
45	17211010		SCREW LT
46	104755X		"J" FASTENER LT"
47	17490612		SCREW
48	17490512		SCREW
49	123481X		SUB= 7605J
50	73680400		SUB= 73690400
53	17490608		SCREW LT
56	74780512		BOLT
57	73510500		NUT
58	136619		BRKT FENDER
59	74180512		SCREW
60	73680500		SUB= 73690500
61	19131210		WASHER
65	72110606		BOLT
67	74191008		SCREW
68	10071000		LOCKWASHER
69	2029J		WELDNUT
70	109808X		HOOD LATCH T
71	74981020		SCREW
72	7206J		SPACER LT
73	73731000		NUT
77	19070818		WASHER
79	2751R		CLIP T
84	19111116		WASHER
90	136462		"BAFFLE,VERTICLE"
95	123198X		SUB= 146525
99	109458X		FOAM STRIP T
100	126471X		"CLIP,INSULATOR"

Ref #	Part Number	Qty	Description
101	110852X		SUPPORT LH YTH
102	110853X		SUPPORT RH YTH
105	132644		SUB= 532132644
107	134774		PIVOT BRKT LH
108	134775		PIVOT BRKT RH
109	72140608		SUB= 72110608
112	110855X		SUPPORT LH YTH
113	110854X		SUPPORT RH YTH
114	17490412		SCREW HEX CRT
115	19091016		WASHER
116	19111212		WASHER
117	74760616		BOLT
118	73800600		NUT
119	72140608		SUB= 72110608
120	74760614		SUB= 74760616



Engine Parts 14 HP Model 400707-1520-01




Ref #	Part Number	Qty	Description
1	494533		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
15A	94497		PLUG, PIPE
16	393382		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
21	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	93882		SCREW, SEMS
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
25A	394956		PISTON ASSEMBLY,.010" OVERSIZE
25B	394957		PISTON ASSEMBLY,.020" OVERSIZE
25C	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	393270		ROD ASSEMBLY, CONNECTING
29A	393714		CONNECTING ROD
32	92909		SCREW, CONNECTING ROD
33	390419		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	280319		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94326		SCREW, AIR CLEANER
90	495026		CARBURETOR ASSY

Ref #	Part Number	Qty	Description
91	495054		BODY ASSY
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	223370		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271609		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491531		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231339		JET, NEEDLE VALVE, FIXED
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	398826		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK, THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	222289		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
232	262539		SPRING, BACKLASH
235	224039		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	492656		HOUSING, BLOWER
305	94608		SCREW, SEMS
305A	94513		SCREW, SEMS, AIR CLEANER
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER

Ref #	Part Number	Qty	Description
307	94386		SCREW, SEMS
308-1	222848		COVER, AIR GUIDE
308-2	222849		COVER, AIR GUIDE
309			REFER TO IMAGE
	394808		MOTOR, STARTING
	94003		BOLT
	395538		BRUSH ASSEMBLY
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	223882		WASHER, GOVERNOR CRANK, INSIDE
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	490421		STARTER DRIVE GROUP
	398003		CLUTCH ASSEMBLY
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
524A	271485		SEAL, FILLER TUBE
525	280224		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
	390837		ARRMATURE ASSEMBLY
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224580		BAFFLE, AIR, CYLINDER
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	223579		COVER, AIR CLEANER
643	223714		CARTRIDGE PLATE, AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR RING
741	262694		GEAR, TIMING

Ref #	Part Number	Qty	Description
	280104		GEAR, STARTER
	394860		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	393825		HOUSING ASSEMBLY
819	94675		SCREW, HEX HEAD
842	271170		SEAL, OIL FILLER CAP
847	394394		DIPSTICK AND TUBE ASSEMBLY
851	221798		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
	490467		PINION SPRING KIT
877	393456		DIODE & CONNECTOR ASSY
881	222860		COVER PLATE, CRANKCASE
	94288		ROLL PIN
955	397882		PLUG & SEAL, SOLENOID
1005	280815		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491260		LABEL KIT

Engine Parts 14 HP Model 400707-1520-01



Ref #	Part Number	Qty	Description
1	494533		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
15A	94497		PLUG, PIPE
16	393382		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
21	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	93882		SCREW, SEMS
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
25A	394956		PISTON ASSEMBLY,.010" OVERSIZE
25B	394957		PISTON ASSEMBLY,.020" OVERSIZE
25C	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	393270		ROD ASSEMBLY, CONNECTING
29A	393714		CONNECTING ROD
32	92909		SCREW, CONNECTING ROD
33	390419		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	280319		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94326		SCREW, AIR CLEANER
90	495026		CARBURETOR ASSY


Ref #	Part Number	Qty	Description
91	495054		BODY ASSY
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	223370		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271609		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491531		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231339		JET, NEEDLE VALVE, FIXED
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	398826		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK, THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	222289		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
232	262539		SPRING, BACKLASH
235	224039		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	492656		HOUSING, BLOWER
305	94608		SCREW, SEMS
305A	94513		SCREW, SEMS, AIR CLEANER
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER

Ref #	Part Number	Qty	Description
307	94386		SCREW, SEMS
308-1	222848		COVER, AIR GUIDE
308-2	222849		COVER, AIR GUIDE
309			REFER TO IMAGE
	394808		MOTOR, STARTING
	94003		BOLT
	395538		BRUSH ASSEMBLY
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	223882		WASHER, GOVERNOR CRANK, INSIDE
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	490421		STARTER DRIVE GROUP
	398003		CLUTCH ASSEMBLY
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
524A	271485		SEAL, FILLER TUBE
525	280224		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
	390837		ARRMATURE ASSEMBLY
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224580		BAFFLE, AIR, CYLINDER
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	223579		COVER, AIR CLEANER
643	223714		CARTRIDGE PLATE, AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR RING
741	262694		GEAR, TIMING

Ref #	Part Number	Qty	Description
	280104		GEAR, STARTER
	394860		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	393825		HOUSING ASSEMBLY
819	94675		SCREW, HEX HEAD
842	271170		SEAL, OIL FILLER CAP
847	394394		DIPSTICK AND TUBE ASSEMBLY
851	221798		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
	490467		PINION SPRING KIT
877	393456		DIODE & CONNECTOR ASSY
881	222860		COVER PLATE, CRANKCASE
	94288		ROLL PIN
955	397882		PLUG & SEAL, SOLENOID
1005	280815		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491260		LABEL KIT

Ref #	Part Number	Qty	Description
1	132747		SUB= 532132748
2	17720410		SCREW LT
3	400707		ENGINE
5	2751R		CLIP T
6	8545J		SUB= 272250
7	10040400		LOCKWASHER
8	74780412		SUB= 74780414
9	13280336		PIPE NIPPLE LT
10	13200300		ELBOW
11	132781		CHOKE CONTROL
13	108373X		MUFFLER HYT
14	11050600		LOCKWASHER
15	73610600		SUB= 7810H
16	100229L		EXHAUST TUBE T
18	11050600		LOCKWASHER
19	17490620		SCREW
20	127813		SUB= 141291
21	123487X		HOSE CLAMP
22	123549X		SUB= 158990
23	123803X		"STRAP,TANK"
24	136360		STRAP ASM. F.TANK
25	17490608		SCREW LT
26	126564X		"STRIP,FORM"
28	7833R		HOSE T
29	132922		SPARK ARREST KIT
30			CHECK WITH SUPPLIER

Engine Parts 14 HP Model 400707-1520-01



Reference Number		309	310	311	544	801	802	803
Manufacturer		Motor and Drive Assy	Thru Bolt Assembly	Brush Assembly	Armature Assembly	Drive End Cap Assembly	End Cap Assy Commutator	Housing Assembly
Briggs & Stratton	Housing Length							
12V	3-5/8"	394808	94003	395538	390837	394860	395537*	393825
JCPenney Part No.		1187-0219	1071-0838	1071-0598	1150-9918	1249-5404	1071-0572	1071-0549

*Includes Brush Set

Reference Number		510	513	783	876	896
Starter Motor Mfr.		Starter Drive Group	Clutch Assembly	Gear	Pinion Spring Kit	Roll Pin
B & S or United Tech.						
12V		490421	398003	280104	490467	94288 (Copper)
JCPenney Part No.		1331-3044	1059-9878	1094-2746	1331-3069	1331-3077


Ref #	Part Number	Qty	Description
1	494533		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
15A	94497		PLUG, PIPE
16	393382		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
21	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	93882		SCREW, SEMS
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
25A	394956		PISTON ASSEMBLY,.010" OVERSIZE
25B	394957		PISTON ASSEMBLY,.020" OVERSIZE
25C	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	393270		ROD ASSEMBLY, CONNECTING
29A	393714		CONNECTING ROD
32	92909		SCREW, CONNECTING ROD
33	390419		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	280319		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94326		SCREW, AIR CLEANER
90	495026		CARBURETOR ASSY

Ref #	Part Number	Qty	Description
91	495054		BODY ASSY
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	223370		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271609		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491531		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231339		JET, NEEDLE VALVE, FIXED
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	398826		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK, THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	222289		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
232	262539		SPRING, BACKLASH
235	224039		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	492656		HOUSING, BLOWER
305	94608		SCREW, SEMS
305A	94513		SCREW, SEMS, AIR CLEANER
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER

Ref #	Part Number	Qty	Description
307	94386		SCREW, SEMS
308-1	222848		COVER, AIR GUIDE
308-2	222849		COVER, AIR GUIDE
309			REFER TO IMAGE
	394808		MOTOR, STARTING
	94003		BOLT
	395538		BRUSH ASSEMBLY
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	223882		WASHER, GOVERNOR CRANK, INSIDE
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	490421		STARTER DRIVE GROUP
	398003		CLUTCH ASSEMBLY
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
524A	271485		SEAL, FILLER TUBE
525	280224		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
	390837		ARRMATURE ASSEMBLY
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224580		BAFFLE, AIR, CYLINDER
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	223579		COVER, AIR CLEANER
643	223714		CARTRIDGE PLATE, AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR RING
741	262694		GEAR, TIMING

Ref #	Part Number	Qty	Description
	280104		GEAR, STARTER
	394860		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	393825		HOUSING ASSEMBLY
819	94675		SCREW, HEX HEAD
842	271170		SEAL, OIL FILLER CAP
847	394394		DIPSTICK AND TUBE ASSEMBLY
851	221798		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
	490467		PINION SPRING KIT
877	393456		DIODE & CONNECTOR ASSY
881	222860		COVER PLATE, CRANKCASE
	94288		ROLL PIN
955	397882		PLUG & SEAL, SOLENOID
1005	280815		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491260		LABEL KIT

Engine Parts 14 HP Model 400707-1520-01




Ref #	Part Number	Qty	Description
1	494533		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
5-1	493457		HEAD, CYLINDER #1
5-2	493458		HEAD CYLINDER #2
7-1	271867		GASKET, CYLINDER HEAD #1
7-2	271868		GASKET, CYLINDER HEAD #2
8-1	495754		BREATHER ASSEMBLY #1
8-2	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
11	280225		TUBE, BREATHER
12	271703		GASKET, CRANKCASE COVER, 1/64"
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
15A	94497		PLUG, PIPE
16	393382		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
18	493304		BASE ASSEMBLY, CRANKCASE
20	291675		SEAL, OIL
21	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	93882		SCREW, SEMS
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	394955		PISTON ASSEMBLY, STANDARD SIZE
25A	394956		PISTON ASSEMBLY,.010" OVERSIZE
25B	394957		PISTON ASSEMBLY,.020" OVERSIZE
25C	394958		PISION ASSEMBLY,.030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	260924		LOCK, PISTON PIN
28	299691		PIN ASSEMBLY, PISTON, STANDARD
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	393270		ROD ASSEMBLY, CONNECTING
29A	393714		CONNECTING ROD
32	92909		SCREW, CONNECTING ROD
33	390419		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
45	261368		TAPPET, VALVE
46	213421		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	280319		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	94326		SCREW, AIR CLEANER
90	495026		CARBURETOR ASSY

Ref #	Part Number	Qty	Description
91	495054		BODY ASSY
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	223370		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271609		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	230896		PIN, FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491531		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231339		JET, NEEDLE VALVE, FIXED
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	398826		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	93535		SCREW, HEX HEAD
201	262683		LINK, GOVENOR
202	262684		LINK, THROTTLE
203	280997		CRANK, BELL
203A	490207		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
216	262375		LINK
219	393415		OIL SLINGER ASSEMBLY
219A	394348		GEAR, GOVERNOR
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	222289		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
232	262539		SPRING, BACKLASH
235	224039		SHIELD, SPITBACK
240	493629		FILTER, FUEL (IN FUEL LINE TO TANK)
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	93949		SCREW, SEMS
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	93496		SCREW, SEMS
284	94264		SCREW, HEX HEAD
284A	93469		SCREW, HEX HEAD
304	492656		HOUSING, BLOWER
305	94608		SCREW, SEMS
305A	94513		SCREW, SEMS, AIR CLEANER
306-1	222846		SHIELD, CYLINDER
306-2	223734		SHIELD, CYLINDER


Ref #	Part Number	Qty	Description
307	94386		SCREW, SEMS
308-1	222848		COVER, AIR GUIDE
308-2	222849		COVER, AIR GUIDE
309			REFER TO IMAGE
	394808		MOTOR, STARTING
	94003		BOLT
	395538		BRUSH ASSEMBLY
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	93381		SCREW, SEM, ARMATURE MOUNTING
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	223882		WASHER, GOVERNOR CRANK, INSIDE
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
467	493903		KNOB, AIR CLEANER
468	224521		SCREEN, FLUSH ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
	490421		STARTER DRIVE GROUP
	398003		CLUTCH ASSEMBLY
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
524A	271485		SEAL, FILLER TUBE
525	280224		TUBE, OIL FILLER
528	393815		HOSE (CUT TO SUIT)
535	271271		ELEMENT, AIR CLEANER
537	271411		GASKET AIR CLEANER
	390837		ARRMATURE ASSEMBLY
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
569	272645		GASKET, CRANKCASE
572	224580		BAFFLE, AIR, CYLINDER
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	223579		COVER, AIR CLEANER
643	223714		CARTRIDGE PLATE, AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR RING
741	262694		GEAR, TIMING

Ref #	Part Number	Qty	Description
	280104		GEAR, STARTER
	394860		CAP, DRIVE
	395537		END CAP ASSY. COMMUTATOR
	393825		HOUSING ASSEMBLY
819	94675		SCREW, HEX HEAD
842	271170		SEAL, OIL FILLER CAP
847	394394		DIPSTICK AND TUBE ASSEMBLY
851	221798		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	393606		SEAL ASSEMBLY AND RETAINER
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
	490467		PINION SPRING KIT
877	393456		DIODE & CONNECTOR ASSY
881	222860		COVER PLATE, CRANKCASE
	94288		ROLL PIN
955	397882		PLUG & SEAL, SOLENOID
1005	280815		FAN, FLYWHEEL
1006	224413		RETAINER, FAN
1019	491260		LABEL KIT

LIFT




Ref #	Part Number	Qty	Description
1	136973		WIRE ASM
2	137111		SHAFT.ASM.LIFT LH
3	138284		PIN GROOVE
4	12000002		SUB= 2225J
5	19211416		WASHER
6	120183X		NYLON BEARING
7	109413X		GRIP
8	124526X		SUB= 125925X
10	122512X		SUB= 532122512
11	134619		LINK LIFT LH
12	135388		LIFT LINK RH
13	4939M		SUB= 85902
14	135563		"PIN,SPRING"
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	130832		SUB= 130833
20	3146R		RETAINER.SPRING




Tractor Parts Model 8927B


SCHEMATIC




SEAT ASSEMBLY




Ref #	Part Number	Qty	Description
1	127432X		SEAT
2	126656X		SUB= 140551
3	74760640		BOLT
4	19131610		WASHER PM
5	2751R		CLIP T
6	73680600		SUB= 73690600
7	124181X		SPRING COMPRESSIO
8	17490640		SCREW
9	19131614		WASHER
10	131451		SUB= 155925
11	121251X		STRIP FORM
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
18	74641008		SUB= 71031008
19	73951000		"NUT,KEPS"
20	4171R		CLIP T
21	105529X		SUB= 139888
22	73680500		SUB= 73690500
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER
27	131772		SEAT SPACER
28	131771		SPLIT SPACER




STEERING ASSEMBLY






Ref #	Part Number	Qty	Description
1	133741		SUB= 150547
2	133988		SUB= 142033
3	135227		SPINDLE LH
4	135228		SPINDLE RH
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	130468		SUB= 532130468
11	10040600		LOCKWASHER
12	73610600		SUB= 7810H
13	110438X		BEARING
14	74011056		BOLT HEX 5/8-11
15	73901000		"NUT-LOC,FLANGE LT"
16	132624		AXLE PIN
17	128758		STEERING SHAFT
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71070410		"SCREW,SPECIAL"
23	127501		SUB= 918127501
24	109816X		NYLINER T
25	124036X		"BRKT,STEERING"
26	12000029		RING
27	136874		GEAR SECTOR
28	6266H		WASHER .T
29	17490612		SCREW
30	10040600		LOCKWASHER
31	73610600		SUB= 7810H
32	130465		TIE ROD
33	126847X		BUSHING.DRAGLINK
34	19131416		WASHER
35	76020412		COTTER PIN
36	1554J		SUB= 155108
37	17431008		SUB= 98000165
38	133742		ST WHL INSERT CAP
39	100712K		WASHER
40	73940800		SUB= 73360800
41	100711L		ADAPTER LT
43	121749X		WASHER
44	121748X		WASHER
45	12000029		RING
46	121232X		CAP
47	6855M		ZERK M

TRANSAXLE DANA - MODEL NUMBER 4360-54




Ref #	Part Number	Qty	Description
1	5305		HOUSING UPPER
2	1919		SCREW
3	5112		BALL, DETENT
4	3626		SPRING, DETENT
5	3623		SCREW, SET
6	4604		KIT, SHIFTER ASSEMBLY
7	5024		BOOT, SHIFTER
8	3907		PUCK, FRICTION
9	5131		SCREW TAPPING WITH SEALER
10	1099		RING RETAINING
11	4689		ASSY, KIT, SHIM .625 SHAFT
12	3707		GEAR SPUR, 15 TEETH
13	3876		WASHER, PLAIN .632 X 1.38 X .046
14	1374		KEY WOODRUFF #9
15	4171		ASSY KIT INPUT SHAFT
16	3725		PINION BEVEL 14 TEETH
17	3624		RING, RETAINING
18	3625		CHAIN, 24 PITCHES
19	1542		BEARING, FLANGE
20	5280		GEAR
21	5303		COLLAR, CLUTCH
22	4759		ASSY, KIT, CLUTCH KEYS
23	5278		BEARING FL
24	5281		SHAFT INTERMEDIATE
25	1375		KEY, WOODRUFF, #61
26	3627		RING, RETAINING
27	3830		SPROCKET, 18 TEETH
28	3841		SPACER
29	3786		GEAR, SPUR, 37 TEETH
30	3785		GEAR, SPUR, 35 TEETH
31	3867		GEAR, SPUR, 30 TEETH
32	3783		GEAR, SPUR, 25 TEETH
33	3869		GEAR, SPUR, 22 TEETH
34	5202		GEAR, SPUR, 19 TEETH
35	3628		WASHER, PLAIN .640 X 1.37 X .061
36	1423		WASHER, PLAIN .632 X 1.00 X .026
37	3422		SPACER .630 X 1.00 X .169
38	4286		ASSY GEAR COMB 12&35 TEETH
39	3967		SHAFT, IDLER
40	3901		SPACER .635 X .875 X .755
41	3645		SPROCKET, 9 TEETH
42	3589		GEAR, BEVEL, 42 TEETH
43	4691		ASSY, KIT, SHIM .750 SHAFT
44	3882		SHAFT, DRIVE
45	3724		SCREW TAPPING
46	3646		GEAR, SPUR, 12 TEETH
47	3866		GEAR, SPUR, 20 TEETH
48	3719		GEAR, SPUR, 25 TEETH
49	3868		GEAR, SPUR, 28 TEETH
50	3683		GEAR, SPUR, 31 TEETH
51	1145		WASHER, PLAIN .632 X 1.00 X .060
52	5130		WASHER, NEOPRENE
53	3184		WASHER, PLAIN .758 X 1.25 X .031
54	3880		AXLE LEFT HAND
55	3871		GEAR MITER 15 TEETH
56	3656		RING, RETAINING
57	3839		GEAR, SPUR, 32 TEETH
58	3919		SHAFT, CROSS


Ref #	Part Number	Qty	Description
59	3726		GEAR, MITER, 15 TEETH
60	3881		AXLE, R.H.
61	5304		HOUSING LOWER
62	3920		PUCK, FRICTION
63	3276		DISC, BRAKE
64	3758		SPACER
65	3916		JAW, BRAKE
66	3843		PIN, DOWEL
67	5120		SCREW, SELF-TAPPING
68	5285		LEVER ACTUATING
69	3760		WASHER, PLAIN .321 X 1.00 X .055
70	3917		BRACKET, ANTI-ROTATION
71	3847		LOCKNUT 5/16-24
72	5279		SQUARE RING
73	4300		GREASE




TRANSAXLE DANA - MODEL NUMBER 4360-54



Ref #	Part Number	Qty	Description
51	1145		WASHER, PLAIN .632 X 1.00 X .060
52	5130		WASHER, NEOPRENE
53	3184		WASHER, PLAIN .758 X 1.25 X .031
54	3880		AXLE LEFT HAND
55	3871		GEAR MITER 15 TEETH
56	3656		RING, RETAINING
57	3839		GEAR, SPUR, 32 TEETH
58	3919		SHAFT, CROSS
59	3726		GEAR, MITER, 15 TEETH
60	3881		AXLE, R.H.
61	5304		HOUSING LOWER
62	3920		PUCK, FRICTION
63	3276		DISC, BRAKE
64	3758		SPACER
65	3916		JAW, BRAKE
66	3843		PIN, DOWEL
67	5120		SCREW, SELF-TAPPING
68	5285		LEVER ACTUATING
69	3760		WASHER, PLAIN .321 X 1.00 X .055
70	3917		BRACKET, ANTI-ROTATION
71	3847		LOCKNUT 5/16-24
72	5279		SQUARE RING
73	4300		GREASE



WHEELS & TIRES



Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	278H		FITTING LT
4	106222X		SUB= 122073X
4A	138468		TIRE.20X8-8
5	59904		TUBE.5.3/4.5/6
5A	7152J		TUBE.18X9.5-8
6	106732X311		SUB= 106732X427
6A	106108X311		SUB= 106108X427
7	104757X		HUB CAP
8	9040H		"FLANGE, BEARING"

