


TRACTOR - - MODEL NUMBER AYP9182B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 42D707, TYPE NUMBER 1280-01




Ref #	Part Number	Qty	Description
	1		497074 CYLINDER ASSEMBLY
	2		399265 P/N CONFLICT - CHECK WITH SUPPLIER
	3		391086 SEAL, OIL
	4		493304 BASE ASSEMBLY, CRANKCASE
	5		493457 HEAD, CYLINDER #1
	5A		493458 HEAD CYLINDER #2
	7		271867 GASKET, CYLINDER HEAD #1
	7A		271868 GASKET, CYLINDER HEAD #2
	8		495754 BREATHER ASSEMBLY #1
	8A		222892 COVER, BREATHER CYLINDER #2
	9		27803 GASKET, VALVE COVER
	10		94382 SCREW, SEMS
	10A		94830 SCREW, SEMS
	11		280225 TUBE, BREATHER
	12		273208 GASKET, CRANKCASE, .015" THICK
	12A		271188 GASKET, CRANKCASE COVER,.005"
	12B		271189 GASKET, CRANKCASE COVER,.009"
	13		94565 SCREW, CYLINDER HEAD
	15		94239 PLUG, OIL DRAIN
	16		394028 CRANKSHAFT
	16A		94196 KEY, TIMING GEAR
	20		291675 SEAL, OIL
	22		94724 SCREW
	23		491180 FLYWHEEL & RING GEAR ASSY, MAGNETO
	24		222698 KEY, FLYWHEEL
	25		498584 PISTON ASSEMBLY STANDARD SIZE
	25A		498585 PISTON ASSEMBLY .010" OVERSIZE
	25B		498586 PISTON ASSEMBLY .020" OVERSIZE
	25C		498507 PISTON ASSEMBLY .030" OVERSIZE
	26		394959 RING SET, PISTON, STANDARD SIZE
	26A		394960 RING SET, PISTON,.010" OVERSIZE
	26B		394961 RING SET, PISTON,.020" OVERSIZE
	26C		394962 RING SET, PISTON,.030" OVERSIZE
	27		263129 LOCK, PISTON PIN
	28		498319 PIN, PISTON, STD SIZE
	28A		391286 PIN ASSEMBLY, PISTON .005" OVER
	29		394306 ROD ASSEMBLY, CONNECTING
	29A		397158 ROD ASSEMBLY, CONNECTING
	32		94671 SCREW, CONNECTING ROD
	33		390420 VALVE, EXHAUST
	34		261528 VALVE, INTAKE
	35		65906 SPRING, INTAKE VALVE
	36		26828 SPRING, EXHAUST VALVE
	40		221596 RETAINER, INTAKE VALVE
	41		292260 RETAINER, EXHAUST VALVE
	42		494553 KEEPER VALVE
	45		261368 TAPPET, VALVE
	46		213520 GEAR, CAM
	50		213290 MANIFOLD, INTAKE
	51		271412 GASKET, CARBURETOR & INTAKE ELBOE
	51A		281411 SPACER, CARBURETOR
	52		270884 GASKET, INTAKE MANIFOLD MOUNTING
	53		93970 SCREW, SEMS, CARBURETOR MOUNTING
	54		93208 SCREW, SEMS INTAKE MANIFOLDING MOUNTING
	75		222511 WASHER SPRING
	78		95039 SCREW HEX
	90		495181 CARBURETOR ASSEMBLY
	91		495035 BODY ASSEMBLY, UPPER CARBURETOR

Ref #	Part Number	Qty	Description
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	231435		PIN FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
117A	231333		JET NEEDLE VALV FXD HI ALT
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
219	394348		GEAR, GOVERNOR
219A	393415		OIL SLINGER ASSEMBLY
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	394358		FILTER, FUEL
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	94906		SCREW
284	94674		SCREW, HEX HEAD
284A	94882		SCREW, HEX HEAD
304	495469		HOUSING, BLOWER, RED
305	94786		SCREW
306	222846		SHIELD, CYLINDER
306A	223734		SHIELD, CYLINDER
307	94930		SCREW
308	224774		COVER, AIR GUIDE
308A	224775		COVER, AIR GUIDE
309	497596		MOTOR, STARTER


Ref #	Part Number	Qty	Description
310	94003		BOLT
311	497608		BRUSH SET
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	497908		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	383815		HOSE, VACUUM
534	94823		SCREW ROUND HEAD
535	272490		ELEMENT, FILTER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	94811		SCREW, HEX HEAD
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
615A	263080		RETAINER
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262989		GEAR, TIMING
783	280104		GEAR, STARTER
801	394860		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP

Ref #	Part Number	Qty	Description
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	497212		SEAL, VALVE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224901		RETAINER, FAN
1019	496726		LABEL KIT
1058	272112		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER



TRACTOR - - MODEL NUMBER AYP9182B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 42D707, TYPE NUMBER 1280-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	493304		BASE ASSEMBLY, CRANKCASE
5	493457		HEAD, CYLINDER #1
5A	493458		HEAD CYLINDER #2
7	271867		GASKET, CYLINDER HEAD #1
7A	271868		GASKET, CYLINDER HEAD #2
8	495754		BREATHER ASSEMBLY #1
8A	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
10A	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	273208		GASKET, CRANKCASE, .015" THICK
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	498584		PISTON ASSEMBLY STANDARD SIZE
25A	498585		PISTON ASSEMBLY .010" OVERSIZE
25B	498586		PISTON ASSEMBLY .020" OVERSIZE
25C	498507		PISTON ASSEMBLY .030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
29A	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	261368		TAPPET, VALVE
46	213520		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	95039		SCREW HEX
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR

Ref #	Part Number	Qty	Description
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	231435		PIN FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
117A	231333		JET NEEDLE VALV FXD HI ALT
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
219	394348		GEAR, GOVERNOR
219A	393415		OIL SLINGER ASSEMBLY
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	394358		FILTER, FUEL
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	94906		SCREW
284	94674		SCREW, HEX HEAD
284A	94882		SCREW, HEX HEAD
304	495469		HOUSING, BLOWER, RED
305	94786		SCREW
306	222846		SHIELD, CYLINDER
306A	223734		SHIELD, CYLINDER
307	94930		SCREW
308	224774		COVER, AIR GUIDE
308A	224775		COVER, AIR GUIDE
309	497596		MOTOR, STARTER


Ref #	Part Number	Qty	Description
310	94003		BOLT
311	497608		BRUSH SET
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	497908		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	383815		HOSE, VACUUM
534	94823		SCREW ROUND HEAD
535	272490		ELEMENT, FILTER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	94811		SCREW, HEX HEAD
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
615A	263080		RETAINER
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262989		GEAR, TIMING
783	280104		GEAR, STARTER
801	394860		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP

Ref #	Part Number	Qty	Description
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	497212		SEAL, VALVE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224901		RETAINER, FAN
1019	496726		LABEL KIT
1058	272112		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER



TRACTOR - - MODEL NUMBER AYP9182B79

BRIGGS & STRATTON ENGINE - MODEL NUMBER 42D707, TYPE NUMBER 1280-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	493304		BASE ASSEMBLY, CRANKCASE
5	493457		HEAD, CYLINDER #1
5A	493458		HEAD CYLINDER #2
7	271867		GASKET, CYLINDER HEAD #1
7A	271868		GASKET, CYLINDER HEAD #2
8	495754		BREATHER ASSEMBLY #1
8A	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
10A	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	273208		GASKET, CRANKCASE, .015" THICK
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	498584		PISTON ASSEMBLY STANDARD SIZE
25A	498585		PISTON ASSEMBLY .010" OVERSIZE
25B	498586		PISTON ASSEMBLY .020" OVERSIZE
25C	498507		PISTON ASSEMBLY .030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
29A	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	261368		TAPPET, VALVE
46	213520		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	95039		SCREW HEX
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR


Ref #	Part Number	Qty	Description
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	231435		PIN FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
117A	231333		JET NEEDLE VALV FXD HI ALT
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
219	394348		GEAR, GOVERNOR
219A	393415		OIL SLINGER ASSEMBLY
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	394358		FILTER, FUEL
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	94906		SCREW
284	94674		SCREW, HEX HEAD
284A	94882		SCREW, HEX HEAD
304	495469		HOUSING, BLOWER, RED
305	94786		SCREW
306	222846		SHIELD, CYLINDER
306A	223734		SHIELD, CYLINDER
307	94930		SCREW
308	224774		COVER, AIR GUIDE
308A	224775		COVER, AIR GUIDE
309	497596		MOTOR, STARTER

Ref #	Part Number	Qty	Description
310	94003		BOLT
311	497608		BRUSH SET
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	497908		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	383815		HOSE, VACUUM
534	94823		SCREW ROUND HEAD
535	272490		ELEMENT, FILTER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	94811		SCREW, HEX HEAD
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
615A	263080		RETAINER
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262989		GEAR, TIMING
783	280104		GEAR, STARTER
801	394860		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP

Ref #	Part Number	Qty	Description
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	497212		SEAL, VALVE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224901		RETAINER, FAN
1019	496726		LABEL KIT
1058	272112		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER



TRACTOR - - MODEL NUMBER AYP9182B79
BRIGGS & STRATTON ENGINE - MODEL NUMBER 42D707, TYPE NUMBER 1280-01




Ref #	Part Number	Qty	Description
1	497074		CYLINDER ASSEMBLY
2	399265		P/N CONFLICT - CHECK WITH SUPPLIER
3	391086		SEAL, OIL
4	493304		BASE ASSEMBLY, CRANKCASE
5	493457		HEAD, CYLINDER #1
5A	493458		HEAD CYLINDER #2
7	271867		GASKET, CYLINDER HEAD #1
7A	271868		GASKET, CYLINDER HEAD #2
8	495754		BREATHER ASSEMBLY #1
8A	222892		COVER, BREATHER CYLINDER #2
9	27803		GASKET, VALVE COVER
10	94382		SCREW, SEMS
10A	94830		SCREW, SEMS
11	280225		TUBE, BREATHER
12	273208		GASKET, CRANKCASE, .015" THICK
12A	271188		GASKET, CRANKCASE COVER,.005"
12B	271189		GASKET, CRANKCASE COVER,.009"
13	94565		SCREW, CYLINDER HEAD
15	94239		PLUG, OIL DRAIN
16	394028		CRANKSHAFT
16A	94196		KEY, TIMING GEAR
20	291675		SEAL, OIL
22	94724		SCREW
23	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
24	222698		KEY, FLYWHEEL
25	498584		PISTON ASSEMBLY STANDARD SIZE
25A	498585		PISTON ASSEMBLY .010" OVERSIZE
25B	498586		PISTON ASSEMBLY .020" OVERSIZE
25C	498507		PISTON ASSEMBLY .030" OVERSIZE
26	394959		RING SET, PISTON, STANDARD SIZE
26A	394960		RING SET, PISTON,.010" OVERSIZE
26B	394961		RING SET, PISTON,.020" OVERSIZE
26C	394962		RING SET, PISTON,.030" OVERSIZE
27	263129		LOCK, PISTON PIN
28	498319		PIN, PISTON, STD SIZE
28A	391286		PIN ASSEMBLY, PISTON .005" OVER
29	394306		ROD ASSEMBLY, CONNECTING
29A	397158		ROD ASSEMBLY, CONNECTING
32	94671		SCREW, CONNECTING ROD
33	390420		VALVE, EXHAUST
34	261528		VALVE, INTAKE
35	65906		SPRING, INTAKE VALVE
36	26828		SPRING, EXHAUST VALVE
40	221596		RETAINER, INTAKE VALVE
41	292260		RETAINER, EXHAUST VALVE
42	494553		KEEPER VALVE
45	261368		TAPPET, VALVE
46	213520		GEAR, CAM
50	213290		MANIFOLD, INTAKE
51	271412		GASKET, CARBURETOR & INTAKE ELBOE
51A	281411		SPACER, CARBURETOR
52	270884		GASKET, INTAKE MANIFOLD MOUNTING
53	93970		SCREW, SEMS, CARBURETOR MOUNTING
54	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
75	222511		WASHER SPRING
78	95039		SCREW HEX
90	495181		CARBURETOR ASSEMBLY
91	495035		BODY ASSEMBLY, UPPER CARBURETOR

Ref #	Part Number	Qty	Description
93	231209		BUSHING, THROTTLE SHAFT
94	491538		VALVE ASSEMBLY, CARBURETOR IDLE
95	93499		SCREW
96	221939		VALVE, THROTTLE
97	392672		SHAFT AND LEVER, THROTTLE
98	91920		SCREW, MACHINE, FILLISTER HEAD
99	26157		SPRING, THROTTLE ADJUSTMENT
102	271607		GASKET, CARBURETOR BODY
103	298514		FLOAT, CARBURETOR
104	231435		PIN FLOAT HINGE
105	394683		VALVE, FUEL INLET
107	491543		BODY, LOWER CARBURETOR
108	223534		VALVE, CHOKE
109	392673		SHAFT AND LEVER, CHOKE
116	280474		O-RING
117	231338		JET, NEEDLE VALVE
117A	231333		JET NEEDLE VALV FXD HI ALT
119	94152		SCREW, SEMS, HEX HEAD
121	491539		CARBURETOR OVERHAUL KIT
127	223472		PLUG, WELCH
161	496599		BODY, AIR CLEANER
165	94289		NUT, WING
187	299146		LINE, FUEL, 28"(CUT TO SUIT)
188	94627		SCREW, SEMS 3/4"
201	262683		LINK, GOVENOR
202	262684		LINK. THROTTLE
203	280997		CRANK, BELL
205	93971		SCREW, SHOULDER
206	94298		NUT, SQUARE
207	262337		SPRING, COMPRESSION
209	262352		SPRING, GOVERNOR
209A	261563		SPRING, GOVERNOR IDLE
219	394348		GEAR, GOVERNOR
219A	393415		OIL SLINGER ASSEMBLY
220	222773		WASHER, THRUST
222	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
224	94297		SCREW, PAN HEAD
227	491297		LEVER ASSEMBLY, GOVERNOR
229	62199		WASHER
230	223882		WASHER, GOVERNOR CRANK, INSIDE
235	224995		SHIELD, SPITBACK
240	394358		FILTER, FUEL
244	230318		CONNECTOR, IMPULSE PUMP
257	93897		SCREW, SEMS
258	94623		SCREW, SEMS, CYLINDER SHIELD MTG.
259	223890		BRACKET, CABLE
265	221535		CLAMP
267	94906		SCREW
284	94674		SCREW, HEX HEAD
284A	94882		SCREW, HEX HEAD
304	495469		HOUSING, BLOWER, RED
305	94786		SCREW
306	222846		SHIELD, CYLINDER
306A	223734		SHIELD, CYLINDER
307	94930		SCREW
308	224774		COVER, AIR GUIDE
308A	224775		COVER, AIR GUIDE
309	497596		MOTOR, STARTER


Ref #	Part Number	Qty	Description
310	94003		BOLT
311	497608		BRUSH SET
332	230674		NUT, HEX
333	394891		ARMATURE GROUP MAGNETRON IGNITION
334	94731		SCREW, SEMS
337	802592		PLUG, SPARK
356	494705		WIRE, STOP
358	491856		GASKET SET
363	19203		PULLER, FLYWHEEL
383	89838		WRENCH SPARK PLUG
387	280197		BODY, PUMP
392	261395		SPRING, PUMP
394	270988		DIAPHRAGM
414	220680		WASHER
422	222875		CLAMP, OIL FILLER
432	221377		CAP, SPRING
434	223688		COVER, DIAPHRAGM
435	93829		SCREW, DIAPHRAGM COVER
445	394019		CARTRIDGE AIR CLEANER
468	497908		SCREEN, ROTATING
474	393474		STATOR, ALTERNATOR, DUAL CIRCUIT
482	93621		SCREW, SEMS
510	497606		DRIVE, STARTER
523	494947		CAP AND DIPSTICK
524	271157		SEAL, FILLER TUBE
525	495348		TUBE, OIL FILLER
528	383815		HOSE, VACUUM
534	94823		SCREW ROUND HEAD
535	272490		ELEMENT, FILTER
537	271411		GASKET AIR CLEANER
544	497603		ARMATURE, STARTER
552	262332		LOWER BUSHING, GOVERNOR
552A	262331		UPPER BUSHING GOVERNOR
556	93585		SCREW, HEX HEAD
562	93853		BOLT, GOVERNOR LEVER
567	94811		SCREW, HEX HEAD
569	272645		GASKET, CRANKCASE
572	224816		BAFFLE, AIR, CYLINDER #2
573	491304		BACK PLATE ASSEMBLY
592	92278		NUT, HEX
601	93053		CLAMP, HOSE, GREEN
615	94296		RETAINER, E-RING
615A	263080		RETAINER
616	491530		CRANK, GOVERNOR
634	271013		WASHER, THROTTLE SHAFT
634A	491287		SEAL, GOVERNOR SHAFT
635	66538		ELBOW, SPARK PLUG
642	225008		COVER, AIR CLEANER
643	496700		CARTRIDGE PLATES AIR CLEANER
653	93585		SCREW, HEX HEAD
726	391362		GEAR, RING
741	262989		GEAR, TIMING
783	280104		GEAR, STARTER
801	394860		CAP, DRIVE
802	497607		P/N CONFLICT - CHECK WITH SUPPLIER
803	497604		HOUSING, STARTER
819	94675		SCREW, HEX HEAD
842	270920		SEAL, OIL FILLER CAP

Ref #	Part Number	Qty	Description
847	495715		DIPSTICK & TUBE ASSY
851	493880		TERMINAL, IGNITION CABLE
858	270989		DIAPHRAGM, DAMPING
859	271025		GASKET, CARBURETOR
860	261358		SPRING, DIAPHRAGM
861	393397		PUMP REPAIR KIT
868	497212		SEAL, VALVE
869	261463		SEAT, INTAKE VALVE, STANDARD
870	213316		SEAT, EXHAUST VALVE, STANDARD
871	261961		GUIDE, EXHAUST VALVE
871A	231218		GUIDE, INTAKE VALVE
877	393456		DIODE & CONNECTOR ASSY
881	495901		COVER PLATE
955	397882		PLUG & SEAL, SOLENOID
1005	281053		FAN, FLYWHEEL
1006	224901		RETAINER, FAN
1019	496726		LABEL KIT
1058	272112		OWNER'S MANUAL
1090	497605		P/N CONFLICT - CHECK WITH SUPPLIER



TRACTOR - - MODEL NUMBER AYP9182B79


CHASSIS AND ENCLOSURES



Ref #	Part Number	Qty	Description
1	159530		CHASSIS ASM
2	140356		SUB= 145009
3	17490612		SCREW
4	19131216		WASHER
5	155272		BUMPER-HOOD/DASH
6	155923		SADDLE
8	126471X		"CLIP,INSULATOR"
9	147627X011		DASH.SILKSCREENED
10	72140608		SUB= 72110608
11	155927		"PANEL-DASH,LH"
12	145660		CLIP.TINNERMAN
13	155934X010		SUB= 169117X010
14	17490608		SCREW LT
15	74180512		SCREW
16	73510500		NUT
17	139394X505		SUB= 159639X505
18	126938X		SUB= 532126938
20	156437		"PLATE-MTG,BATT/FU"
23	124028X		SUB= 532124028
24	74780616		BOLT
25	19131312		WASHER
26	73800600		NUT
28	140434		GRILL.BLK
29	140273		LENS GRILLE
30	147310X505		FENDER LT
31	139976		BRACKET SUPT FEND
33	105476X505		FOOTREST LH
34	105475X505		FOOTREST RH
35	72110606		BOLT
37	17490508		SCREW LT
38	139886		BRACKET ASM LH
39	139887		BRACKET ASM RH
40	139977		SPACER FENDER LT
51	73800400		NUT
52	19091416		WASHER
53	144697		BRACKET.GRILLE.LH
54	17030814		SUB= 91817030814
55	144696		BRACKET.GRILLE.RH
57	74780412		SUB= 74780414
58	140547		DUCT.AIR.B&S.18HP
71	73680400		SUB= 73690400
140	158418		BRKT SUSPENSION
145	156524		"ROD POVOT,CHASSIS"
147	74760412		BOLT LT
	5479J		PLUG BUTTON T
	134014		PLUG DOME


TRACTOR - - MODEL NUMBER AYP9182B79

DECALS




NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

Ref #	Part Number	Qty	Description
1	145005		DECAL.BATRY.3-3908
2	141517		DECAL DECK WIZ +
3	146676		DECAL.HD.RH.WIZAR
4	146615		DECAL.FENDER.WIZ
5	273063		DECAL, HP, ENGINE
6	157002		"DECAL DANGER,FEND"
7	4900J		DECAL T
8	146677		DECAL.HD.LH.WIZAR
9	143349		"DECAL.CHASSIS.42"""
10	158270		DECAL INSERT HOOD
13	146678		DECAL.INS.STRG.WL
15	136832		DECAL
16	127521		NLA
19	156868		"DECAL INST,SADDLE"
	138311		DECAL HANDLE LIFT
	142341		DECAL DRAWBAR LH
	159740		MANUAL.O.9182B79




TRACTOR - - MODEL NUMBER AYP9182B79

DRIVE




Ref #	Part Number	Qty	Description
1	205-026B		TRANSAXLE, PEERLESS
2	146682		SPRING.BRAKE.RETU
5	121520X		STRAP TORQUE
6	17490512		SCREW
8	141003		ROD SHIFT FEND LT
10	76020416		PIN COTTER 1/8
13	74550412		BOLT.1/4-28.W/PAT
15	74490544		BOLT.HX.FLG.5/16
18	74780616		BOLT
19	73800600		NUT
21	106933X		KNOB T (1/2-HOLE)
22	130804		BRAKE ROD
24	73350600		NUT
25	106888X		SPRING ROD LT
26	19131316		WASHER
27	76020412		COTTER PIN
28	145204		ROD.BRAKE.PARK.LT
29	71673		PLUNGER CAP T
30	130807		TRANSAXLE MTG BKT
32	74760512		BOLT
34	155071		SHAFT ASM-PEDAL F
35	120183X		NYLON BEARING
36	19211616		WASHER LT
37	1572H		SUB= 2882J
38	123674X		PULLEY.IDLER.FLAT
39	74760644		BOLT
40	4470J		SPACER T
41	154777		SUB= 165692
42	19131312		WASHER
47	127783		SUB= 139245
48	154604		BELLCRANK ASM
49	123205X		RETAIN BELT
50	74760624		SUB= 74930624
51	73680600		SUB= 73690600
52	73680500		SUB= 73690500
53	105710X		"LINK, CLUTCH T"
55	105709X		"SPRING, RETURN LT"
56	74760620		SUB= 74780620
57	156971		"V-BELT,GRD DRIVE"
59	140312		KEEPER BELT CNTSP
61	17490612		SCREW
62	8883R		PEDAL COVER T
63	140186		PULLEY.ENGINE
64	71170764		BOLT
65	10040700		LOCKWASHER
66	154778		KEEPER-BELT
69	142432		SCREW HEXWSH H-L
70	134683		KEEPER BELT ENG
72	19132012		WASHER
74	156972		"SPACER AXLE,PVST"
75	121749X		WASHER
76	12000001		E-RING LT
77	123583X		SQUARE KEY
78	121748X		WASHER
81	156969		SHAFT ASM CROSS
82	123782X		"SPRING,TORSION"
83	19171216		WASHER
84	156962		"ROD TIE, PVST 20"

Ref #	Part Number	Qty	Description
86	71208		BUSHING
87	19212016		WASHER D
88	12000008		KLIP RING
89	151147		SUB= 164893
95	156970		ROAD ASM BYPASS
96	4497H		RETAINER M
100	19111216		WASHER M
113	127285X		"STRAP,TORQUE"
116	72110610		BOLT RDHD 3/8-16
118	154774		SPACER-BELLCRANK
121	154419		NYLINER-CLUTCHING
122	156963		"PLATE-BYPASS,PVST"
123	19081016		WASHER
124	156967		SPRING RETURN
125	74780516		SUB= 77394
126	1685H		SUB= 68478



TRACTOR -- MODEL NUMBER AYP9182B79


ELECTRICAL



Ref #	Part Number	Qty	Description
1	144925		SUB= 123899X
2	74760412		BOLT LT
3	19091016		WASHER
4	10040400		LOCKWASHER
6	73220400		SUB= 50675
7	109238X		TUBE T
8	156417		"CASE,BATTERY.MECH"
9	109596X		HOSE CLAMP T
15	147688		FASTNER.SNAP-IN
16	153664		SWITCH INTERLOCK
19	10090400		SUB= 10040400
20	73350400		NUT
21	136850		"HARNES,LIGHT SOC"
22	4152J		HEADLAMP BULB
24	4799J		"CABLE T, BATTERY"
25	146147		CABLE.BTRY.6GA.RD
26	108824X		FUSE HYT
28	4207J		CABLE T
29	121305X		SWITCH SEAT
30	140301		SWITCH IGN 4POS
31	124211X		NUT IGNITION
32	141226		COVER KEY SWITCH
33	122147X		KEY
40	156442		HARNES-IGNITION
41	71110408		BOLT HXHD FIN
42	131563		SUB= 154336
43	145673		SUB= 146154
44	73640400		NUT HXKEP 1/4X20
48	140844		ADAPTER AMMETER
52	141940		PROTECTION LOOP
70	140413		HARNES ENG DUAL

TRACTOR -- MODEL NUMBER AYP9182B79


ENGINE




Ref #	Part Number	Qty	Description
1	141295		CONTROL THRT 35.5
2	17720410		SCREW LT
3			REFER TO IMAGE
4	149723		MUFFLER.TW.LOTONE
5	144069		EXHAUST.B&S.18.LH
6	144068		EXHAUST.B&S.18.RH
7	138129		CLAMP.TUBE.DBL.EN
8	150176		BOLT.5/16-18.UNC
10	145552		SHIELD.HEAT.
11	10040400		LOCKWASHER
12	74780412		SUB= 74780414
13	272250		GASKET MUFFLER
14	13280336		PIPE NIPPLE LT
15	13200300		ELBOW
16	11050600		LOCKWASHER
17	17490624		SCREW LT
23	156123		SHIELD-HEAT
25	145996		CONTROL.CHOKE.37
26	73920600		"NUT,KEPS 3/8-24IM"
27	152927		"SCREW-TT,10-32 FL"
29	137180		SUB= 532137180
31	140280		SUB= 161911
32	140527		CAP ASM FUEL
33	123487X		HOSE CLAMP
35	17490512		SCREW
37	137040		LINE FUEL
38			CHECK WITH SUPPLIER
40	124028X		SUB= 532124028
44	17490412		SCREW HEX CRT
46	19091416		WASHER
81	128861		NUT

TRACTOR - - MODEL NUMBER AYP9182B79

LIFT




Ref #	Part Number	Qty	Description
1	159460		WIRE ASM W.SPRING
2	159471		"SHAFT ASM LIFT,RH"
3	105767X		PIN-GROOVE LT
4	12000002		SUB= 2225J
5	19211621		WASHER
6	120183X		NYLON BEARING
7	109413X		GRIP
8	124526X		SUB= 125925X
1	139865		SUB= 918139865
12	139866		SUB= 151140
13	4939M		SUB= 85902
15	127218		LINK.FRONT
16	73350800		NUT
17	130171		TRUNION
18	73800800		NUT.LK.W/WSH.1/2.
19	139868		ARM SUSP REAR
20	3146R		RETAINER.SPRING
31	140302		BEARING PVT LH
32	73540600		NUT.CROWNLOCK.3/8



TRACTOR -- MODEL NUMBER AYP9182B79

MOWER DECK





Ref #	Part Number	Qty	Description
1	144393		DECK.WELD.42.
2	72140506		BOLT
3	138017		BRKT ASM SWAY BAR
4	138440		BRKT DECK SW BAR
5	4939M		SUB= 85902
6	130832		SUB= 130833
8	850857		BLADE BOLT
9	10030600		SUB= 10040600
10	140296		WASHER.HARD.BLADE
11	134149		"BLADE.42"" MULCHER"
12	129895		BEARING.BALL
13	137645		SUB= 137646
14	128774		HSG ASM MANDREL
15	110485X		BEARING
16	140329		STRIPPER RND MWR
17	72110610		BOLT RDHD 3/8-16
18	72140505		BOLT
19	132827		BOLT SHD 5/16-18
20	136888		SUB= 918136888
21	73680500		SUB= 73690500
22	134753		STIFFENER BRKT
23	131267		DEFLECTOR BRKT
24	105304X		CAP-SLEEVE LT
25	123713X		SPRING TORSION
26	110452X		NUT PUSH M
27	130968		DEFLECTOR.SHIELD
28	19111016		WASHER
29	131491		HINGE ROD
30	138776		SUB= 157722
31	129963		WASHER
32	153535		PULLEY.MANDREL.42
33	137266		SUB= 139729
34	72110614		BOLT
35	133835		XMAS TREE FASTNER
36	131494		FLAT IDLER PULLEY
37	19131316		WASHER
40	73680600		SUB= 73690600
41	133551		PIVOT ROD
43	140083		ROD CLUTCH W/NIBS
44	140088		GUARD MAND LH BLK
45	4497H		RETAINER M
46	137729		SCREW.1/4-20X5/8
48	133944		HARD SMALL WASHER
49	155066		ROLLER ASM-CAM
50	131340		SHOULDER BOLT
51	69180		LOCKNUT
52	139888		BOLT.SHLD.5/16-18
53	131845		BRAKE PAD ARM ASM
54	133943		HARDENED WASHER
55	155046		ARM-IDLER
56	122052X		SPACER RETAINER
58	140086		SPRING TORSN BRAK
59	141043		GUARD IDLER TUV
67	106932X		KNOB T(3/8 HOLE)
68	144200		BELT.V.T-PATH
71	142427		ROD CLUTCH 38/42
72	131870		RETURN SPRING
73	127847		CLUTCH ARM SECOND

Ref #	Part Number	Qty	Description
74	121748X		WASHER
75	12000029		RING
76	128903		SHOULDER BOLT
77	127845		SPRING KEEPER
78	154809		LEVER ASM-CLUTCH
79	127498		BUSHING
80	153701		SPRING.CLUTCH.MWR
81	73350600		NUT
82	142028		TRUNION ADJ
83	120958X		WASHER
84	156084		"KEEPER-BELT,FIXED"
85	72140618		BOLT RDHD 3/8-16
92	73800600		NUT
101	136420		"COVER.MULCH.42""
102	71161010		SCREW
103	19061216		WASHER #10
104	1007100		WASHER LOCK #10
105	130758		SUB= 160793
106	2029J		WELDNUT
111	155197		BRACKET.GWHL.LH.
112	155198		BRACKET.GWHL.RH.
113	17490512		SCREW
114	73510500		NUT
115	72110504		SUB= 872110504
116	4898H		BOLT M
117	105455X		WHEEL.GAGE.BLK.PL
118	73930600		LOCKNUT
119	19121414		WASHER
120	19171512		WASHER
121	143723		BRACKET.EXTRD.GWL
128	153390		WASHER.FELT.
132	19132203		WASHER GT
	130794		MANDREL ASM
	159481		SUB= 145411

TRACTOR - - MODEL NUMBER AYP9182B79

SCHEMATIC



IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	G + M + L	NONE
RUN/LIGHT	B + L	A + Y
RUN	B + L	NONE
START	B + L + S	NONE


NOTE
YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM, AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.

NON-REMOVABLE CONNECTIONS REMOVABLE CONNECTIONS

WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.


TRACTOR - - MODEL NUMBER AYP9182B79

SEAT ASSEMBLY




NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

Ref #	Part Number	Qty	Description
1	127427		SUB= 140119
2	140551		BRACKET PVT SEAT
3	74760616		BOLT
4	19131610		WASHER PM
5	145006		CLIP.PUSH-IN.HING
6	73800600		NUT
7	124181X		SPRING COMPRESSIO
8	17490616		SCREW GTV
9	19131614		WASHER
10	155925		PAN-SEAT
12	121246X		BRKT SWITCH
13	121248X		BUSHING
14	72050411		SUB= 872050411
15	134300		SPLIT SPACER
16	121250X		SPRING
17	123976X		SUB= 73900400
21	153236		"BOLT,SHOULDER"
22	73800500		NUT
23	74780814		BOLT
24	19171912		WASHER
25	127018X		"BOLT,SHOULDER"
26	10040800		LOCKWASHER



TRACTOR -- MODEL NUMBER AYP9182B79


STEERING ASSEMBLY




Ref #	Part Number	Qty	Description
1	140044		WHEEL STR AYP BLK
2	154427		AXLE ASM
3	156483		SPINDLE.ASM.LH
4	157473		"SPINDLE ASM,RH"
5	6266H		WASHER .T
6	121748X		WASHER
7	19272016		WASHER
8	12000029		RING
9	3366R		COL. SRTG. BEAR.
10	156438		DRAGLINK-STAMPED
11	10040600		LOCKWASHER
13	154779		BEARING AXLE
15	73901000		"NUT-LOC,FLANGE LT"
17	156546		SHAFT ASM STEERIN
18	57079		THRUST WASHER
19	124035X		SUPPORT.SHAFT
20	126684X		SUB= 532126684
21	10040400		LOCKWASHER
22	71100410		SCREW.SCKTHD.CAP
23	127501		SUB= 918127501
25	154406		BRKT-STEERING
26	126847X		BUSHING.DRAGLINK
27	136874		GEAR SECTOR
28	19131416		WASHER
29	17490612		SCREW
30	76020412		COTTER PIN
32	130465		TIE ROD
36	155099		BUSHING.STEERING
37	152927		"SCREW-TT,10-32 FL"
38	140045		CAP STEER AYP
39	19133808		WASHER T
40	7810H		GRIPCO NUT
41	100711L		ADAPTER LT
42	145054		BOOT.STEER.PL
43	121749X		WASHER
44	153720		EXT SHAFT STEERIN
46	121232X		CAP
47	6855M		ZERK M
51	73800500		NUT
53	73680600		SUB= 73690600
54	74780520		BOLT
62	156594		KIT STEERING ASM
63	74780616		BOLT
65	154780		SPACER AXLE
66	154404		"BEARING-ARM,PITMA"
67	74781044		BOLT
68	154429		BRACE AXLE
69	160367		"SPACER BRCAE,AXLE"
70	74780636		BOLT.HEX.3/8-16X2

**TRACTOR - - MODEL NUMBER AYP9182B79
TRANSAXLE PEERLESS - MODEL NUMBER 205-026B**


TRANSAXLE



Ref #	Part Number	Qty	Description
36	790075		BRAKE DISC
37	790007		PLATE BRAKE PAD
38	799021		BRAKE PAD
39	786026		PIN DOWEL
40	792076A		WASHER
41	790085		BRAKE LEVER
42	792073		SCREW, 1/4-20 X 1-1/4
42A	792085A		SCREW, 1/4-20 X 2-1/4
43	792075		LOCKNUT 5/16-24
44	790025		HOLDER BRAKE PAD
45	786066		SPACER
46	790086		BRAKE LEVER BRACKET
71	788069		SEAL SQUARE CUT
71A	792162		PUSHNUT
79	792144		SPRING
87	788035		OIL SEAL
180	730229A		GEAR OIL 80W90
189	792168		DRIVE SCREW
189A	792169		SCREW
190	792150		LOCKWASHER
191	792151		NUT
208B	798025		FAN/COUPLING
209	798024		CONTROL LEVER



WHEELS & TIRES



NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

Ref #	Part Number	Qty	Description
1	59192		VALVE CAP
2	65139		VALVE STEM LT
3	106222X		SUB= 122073X
4	59904		TUBE.5.3/4.5/6
5	106732X427		"RIM ASM 6"" FRT"
6	278H		FITTING LT
7	9040H		"FLANGE, BEARING"
8	106108X427		"RIM AS 8"" REAR"
9	138468		TIRE.20X8-8
10	7152J		TUBE.18X9.5-8
11	104757X		HUB CAP
	144334		SEALANT.TIRE 10 OZ. TUBE

