


DECALS




Ref #	Part Number	Qty	Description
1	137457		DECAL.PNL.CNT.
2	137461		DECAL.SHLD.TINE
3	137462		DECAL.GD.BELT 5HP
4	136943		DECAL.INSTRUCTION
5	120431X		DECAL TI
6	102180X		DECAL CRT
7	110593X		SUB= 121858X
8	121543X		SUB= 271948
9	120075X		DECAL TI
	137177		MANUAL.O850-01000



Engine Parts 6 HP Model 135202-0146-01

Specify Model and Part
Number When Ordering




Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER

Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
306	221511		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING

Ref #	Part Number	Qty	Description
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER

Engine Parts 5 HP Model 135202-0145-01

Specify Model and Part
Number When Ordering



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL

Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER


Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
306	221511		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING



Ref #	Part Number	Qty	Description
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER

Engine Parts 5 HP Model 136202-0145-01

Specify Model and Part
Number When Ordering




Ref #	Part Number	Qty	Description
1	395990		CYLINDER ASSEMBLY
2	297565		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
	270125		GASKET, CRANKCASE .005" THICK
	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	93448		PLUG, PIPE, HEX SOCKET
	94387		PLUG OIL DRAIN
16	492088		CRANKSHAFT
	230978		CRANKSHAFT GEAR PIN
18	297602		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	66768		PLUG, OIL FILLER
22	94682		SCREW
23	297229		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	298904		PISTON ASSEMBLY, STANDARD
	298905		PISTON ASSEMBLY .010" OVERSIZE
	298906		PISTON ASSEMBLY .020" OVERSIZE
	298907		PISTON ASSEMBLY .030" OVERSIZE
26	298982		RING SET, PISTON, STANDARD
	299742		RING SET, PISTON, CHROME, STANDARD
	298983		RING SET, PISTON .010" OVERSIZE
	298984		RING SET, PISTON .020" OVERSIZE
	298985		RING SET, PISTON .030" OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
	390459		ROD ASSEMBLY, CONNECTING
30	221890		DIPPER, CONNECTING ROD
32	94745		SCREW, CONNECTING ROD
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
52	271936		GASKET, INTAKE ELBOW MOUNTING
55	494846		HOUSING, REWIND STARTER
56	493824		PULLEY, REWIND STARTER
57	262594		SPRING, REWIND STARTER
58	280406		ROPE, REWIND STARTER
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
69	280973		WASHER

Ref #	Part Number	Qty	Description
69A	224322		WASHER
73	224632		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	495426		CARBURETOR ASSEMBLY
95	93499		SCREW
96	223793		THROTTLE, CARBURETOR
97	490048		SHAFT AND LEVER THROTTLE
108	491177		VALVE AND SHAFT GROUP, CHOKE
118	231533		VALVE, NEEDLE
121	495606		CARBURETOR OVERHAUL KIT
124	94616		SCREW, ELBOW MOUNTING
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
149	26336		SPRING, NEEDLE VALVE
152	260575		SPRING, THROTTLE ADJUSTMENT
153	490589		SCREW AND COLLAR
154	93527		SCREW, MACHINE, ROUND HEAD
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
190	94712		SCREW, FUEL TANK
190A	94677		SCREW, FUEL TANK MOUNTING 1-3/4"
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
204	222962		BUSHING, GOVERNOR LEVER, FLAT
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262283		SPRING, GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
223	223455		LEVER, GOVERNOR CONTROL
224	93491		RIVET, GOVERNOR CONTROL LEVER MOUNTING
227	490374		LEVER ASSEMBLY, GOVERNOR
230	222450		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
257	93543		SCREW, SEMS, HEX HEAD
300	393615		MUFFLER, EXHAUST
304	495759		HOUSING, BLOWER
306	221511		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	92284		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	93705		SUB= 69485
356	398808		WIRE, GROUND
363	19069		PULLEY, FLYWHEEL
373	92987		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING



Ref #	Part Number	Qty	Description
433	93265		PIN, DIAPHRAGM COVER
434	214021		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM
455	224250		CUP, STARTER
456	224321		RETAINER, REWIND STARTER
459	492833		PAWL, STARTER
461	262626		PIN, STARTER
467	280715		KNOB, CONTROL
515	262625		SPRING, TORSION
526	94659		SCREW,SEMS,TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
542	93572		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	92613		BOLT, GOVERNOR LEVER
592	231082		NUT, HEX
608	495766		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
615	93307		RETAINER, E-RING
616	231077		CRANK, GOVERNOR
621	396847		SWITCH, STOP
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	261696		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	221798		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	211172		SEAT, INTAKE VALVE, STANDARD
871	262001		GUIDE, EXHAUST VALVE
	63709		GUIDE, INTAKE VALVE
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495357		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94018		SCREW, AIR CLEANER
987	398970		SEAL, THROTTLE SHAFT
995	223887		BRACKET, CONTROL LINK
1012	490507		RETAINER, LINK
1016	224278		COVER, REWIND STARTER


HANDLE ASSEMBLY



NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm


Ref #	Part Number	Qty	Description
1	71091008		SCREW
2	126951X		"PANEL,CONT TI"
3	104164X		TIE CABLE CRT
4	8206H		GRIP T
5	4497H		RETAINER M
6	581328		BOLT, SHOULDER
7	109335X		SHIFT HANDLE CRT
8	109313X		GROMMET CRT
9	109337X		SHIFT ROD CRT
10	72110608		BOLT D
11	109229X		LOCK CRT
12	73930600		LOCKNUT
13	19131611		WASHER CRT
14	109228X		LEVER LOCK CRT
15	127013X473		SUB= 155117
16	10040400		LOCKWASHER
17	73220400		SUB= 50675
18	73731000		NUT
19	102162X		CABLE.CLUTCH.CRT
20	9484R		CONDIUT CLIP T
21	86777		SUB= 750097
22	102604X		GRIP BAR CRT
23	102744X		SUB= 102744X431
24	105216X		"ASSY CONTROL, BAR"
25	127012X		"CONT,THROTTLE"
26	72140404		BOLT
27	9266R		SUB= 624A78

MAINFRAME, LEFT SIDE



Ref #	Part Number	Qty	Description
1	73510500		NUT
2	10040600		LOCKWASHER
3	73220600		NUT.HEX.3/8-16UNC
4	74930568		BOLT TI
5	1572H		SUB= 2882J
6	110111X		LEVER ASM CRT
7	72110404		BOLT
8	8700J		PANEL TI
9	86777		SUB= 750097
10	9484R		CONDIUT CLIP T
11	10040400		LOCKWASHER
12	73220400		SUB= 50675
13	23230506		SET SCREW
14	120938X		SPACER
15	19111116		WASHER
16	100473M		"SHEAVE 10"" CRT"
17	73220500		NUT.HEX.5/16-18
18	110651X		SPACER CRT
19	2649M		KEY T
20	110653X		GUARD CRT
21	131691		SPLIT SPACER
22	104214X		NUT TI
23	102190X		TIRE.CHV.13X5.0-6
	124258X		RIM
	795R		SUB= 65139
24	126875X		RIVET.DRILL.1.75
25	4497H		RETAINER M
26	131159X473		"GUARD, BELT"
27	132672		BELT-V
28	104679X		PULLEY-IDLER TI
29	12000032		KLIP RING
30	105611X		SUB= 918105611X
31	102384X		BOLT CRT
32	102141X		SHIFT ARM CRT
33	74760616		BOLT
34	102383X		COUNTERWEIGHT CRT
35	74760524		BOLT.HEX.5/16-1.5
36	102331X		BRACKET LH CRT
37	130816		ENGINE SHEAVE
38	131558		BELT GUARD BRKT


MAINFRAME, RIGHT SIDE



Ref #	Part Number	Qty	Description
1	73510500		NUT
2	102332X		BRACKET RH CRT
3	74760524		BOLT.HEX.5/16-1.5
4	102173X		COUNTERWEIGHT CRT
5	10040600		LOCKWASHER
6	73220600		NUT.HEX.3/8-16UNC
7	4497H		RETAINER M
8	126875X		RIVET.DRILL.1.75
9	102190X		TIRE.CHV.13X5.0-6
	124258X		RIM
	795R		SUB= 65139
10			REFER TO IMAGE




TINE ASSEMBLY




Ref #	Part Number	Qty	Description
1	4459J		SUB= 6554J
2	132673		PIN.CLEVIS.SHEAR
3	6554J		"TINE.LH.12""
4	3146R		RETAINER.SPRING
5	132727		HUB&PLATE ASM LH
6	73610600		SUB= 7810H
7	10040600		LOCKWASHER
8	74610616		BOLT
9	4460J		SUB= 6555J
10	132728		HUB&PLATE ASM RH
11	6555J		"TINE.RH.12""




TINE SHIELD



Ref #	Part Number	Qty	Description
1	98000129		NUT
2	104086X473		SHIELD.SD.OUT.LH
3	8393J		STAKE PIN TI
4	12000036		KLIP RING TI
5	72110508		BOLT CRT
6	8394J		SPRING TI
7	8392J		LATCH BRACKET TI
8	109230X		SPRING CRT
9	102326X473		"SHIELD, TINE"
10	72140506		BOLT
11	73220500		NUT.HEX.5/16-18
12	10040500		LOCKWASHER
13	72110510		BOLT
14	124343X		BRKT SHIELD TINE
15	104101X473		SUB= 104101X421
16	73220400		SUB= 50675
17	10040400		LOCKWASHER
18	72040410		BOLT
19	102701X		GRIP CRT
20	73220600		NUT.HEX.3/8-16UNC
21	102156X		SUB= 102156X500
22	74930632		BOLT
23	4440J		HINGE CRT
24	72140404		BOLT
25	6712J		VINYL CAP TI
26	109227X		PAD IDLER TI
27	102695X473		"SHIELD, LEVELING"
28	120588X		PIN HINGE
29	104085X473		"SHIELD, SIDE"



TRANSMISSION



NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

Ref #	Part Number	Qty	Description
1	137555		SUB= 155112
2	121147X		SUB= 150698
3	106211X		GASKET TI
4	5020J		NEEDLE BRNG LT
5	1370H		"T, BEARING"
6	102113X		PINION-INPUT CRT
7	102110X		SHAFT-INPUT CRT
8	4895H		"TI, BEARING"
9	102136X		WASHER SEAL CRT
10	57392M		BALL, STEEL
11	100371K		SPRING-SHIFT CRT
12	106160X		O-RING TI
13	102107X		ARM ASSY CRT
14	8353J		SHIFT FORK TI
15	12000039		KLIP RING
16	102109X		SHAFT SHIFT CRT
17	104159X		SPACER SPLIT CRT
18	4358J		WASHER
19	12000040		KLIP RING
20	102114X		GEAR ASSY CRT
21	102115X		GEAR-REV IDLR CRT
22	6803J		NEEDLE BEARING TI
23	102111X		SHAFT CRT
25	10040700		LOCKWASHER
26	102128X		O RING CRT
27	102100X		"CRT, BEARING"
28	106390X		BUSHING TI
29	109204X		SUB= 150737
31	102106X		SUB= 918102106X
32	106388X		SPACER TI
33	102121X		SPRCKT 8 GEAR CRT
34	102112X		SHFT 2ND RED. CRT
35	102101X		SCRW WHIZ LOK CRT
36	137300		SPROCKET ASM.
37	4422J		BEARING
38	137301		SUB= 137300
39	105345X		GEAR TI
40	105346X		GEAR TI
41	8358J		REDUCTION SHFT TI
43	4220R		BRNG RACE
44	9672R		CUP.FORMED.
45	102144X		RING SPIRAL CRT
46	9676R		SUB= 147344
47	9674R		SUB= 147344
48	121745X		SUB= 150700
49	132688		TINE SHAFT
50	106147X		CHAIN.50 LINK TI
51	17580408		SCREW CRT
52	73220500		NUT.HEX.5/16-18