



BLOWVAC

LS1500----B

TYPE 5



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants	
101	1	370083-07	ANKER ZSB		DE
102	1	370084-09	FELD		DE
103	1	572261-04	GEHAEUSEPAAR		
104	1	374809-02	GEHAEUSE		
107	2	844217-02	SPEZIALSCHRAUBE		
108	2	370983-02	KOHLE + HALTER 230V		
109	1	370087	GEHAEUSE		
110	1	370009	LUEFTER		
111	1	372689-49	MUTTER U.KAPPE (SET)		
112	1	375001-01	SCHIEBER		
113	1	578773-00	ANTRIEB		
114	1	370027	FEDER		
115	1	370012	RASTER		
116	1	370020	KABELFUEHRUNG		
117	1	572729-01	KABELSATZ (EURO)		DE
118	1	376086-49	SCHALTER ZSB		
119	23	747329	SCHRAUBE		
121	1	374996-09	GEHAEUSE		
123	1	374993-02	GEHAEUSE		
125	1	377763-01	LAUFWAGEN		
127	1	573411-01	BEUTEL ZSB		
130	1	579956-00	WARNSCHILD		
131	1	372648	LITZE ZSB		DE
132	1	572267-01	ABSAUGSCHLAUCH KIT		
133	1	572587-01	LUFTSCHLAUCH KIT		
140	1	574756-00	UNTERLEGSCHIEBE		
876	1	370082-12	MOTOR ZSB		DE