



BLOWVAC

LS1800----A

TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants
1	1	583340-01	GEHAEUSEPAAR	
2	1	589453-00	MOTOR ZSB	
3	1	587955-00	LÜFTER	
4	1	585241-00	MUTTER	
5	1	583345-00	SCHIEBER	
6	1	583346-01	RASTER	
7	1	583347-01	HEBEL	
8	1	586066-00	SCHALTER + DIODE	
9	1	583349-00	FEDER	
10	1	583344-00	ANTRIEB	
13	1	584928-00	KABELSATZ (EURO)	DE
15	1	329301-00	KABELKLEMME	
16	2	747329	SCHRAUBE	
17	1	583498-09	WARNSCHILD	
18	26	747329	SCHRAUBE	
20	1	583495-02	TYPENSCHILD	
21	1	583351-02	GEHAEUSEPAAR	
22	1	584268-01	ABSAUGSCHLAUCH KIT	
24	1	584269-00	GEHAEUSEPAAR	
25	1	583343-02	SCHILD	
26	1	583504-02	SCHILD	
27	1	583485-00	GEHAEUSEPAAR	
28	1	583488-01	LUFTSCHLAUCH KIT	
30	1	583505-00	BEUTEL ZSB	
31	1	583493-00	BAND	
33	1	586642-00	FEDER	