

## STICHSÄGE

## KS634S----A



## TYPE 1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants	
1	1	571299-17	MOTOR ZSB		A9-B1-XD
1	1	571299-17	MOTOR ZSB		GB
1	1	571299-17	MOTOR ZSB		IE
1	1	571299-17	MOTOR ZSB		KW
1	1	571299-19	MOTOR ZSB		TW
1	1	576376-03	MOTOR ZSB		NL
1	1	576376-03	MOTOR ZSB		NO
1	1	576376-03	MOTOR ZSB		SE
1	1	576376-03	MOTOR ZSB		FR
1	1	576376-03	MOTOR ZSB		GR
1	1	576376-03	MOTOR ZSB		IT
1	1	576376-03	MOTOR ZSB		DK
1	1	576376-03	MOTOR ZSB		ES
1	1	576376-03	MOTOR ZSB		FI
1	1	576376-03	MOTOR ZSB		AT
1	1	576376-03	MOTOR ZSB		BE
1	1	576376-03	MOTOR ZSB		DE
1	1	576376-03	MOTOR ZSB		CH-XE
2	1	580486-01	GEHAEUSEPAAR		KS638SE
2	1	000000-00	NICHT MEHR LIEFERBAR		KS635S - KS634S
3	1	000000-00	NICHT MEHR LIEFERBAR		
4	1	807285-06	KONDENSATOR		KS635S - KS634S
5	1	368329-00	PCB		KS638SE-EXCEPT TW
5	1	368329-01	PCB		KS638SE-TW
6	1	770235	SCHUTZ		
7	1	330060-53	KABELSATZ		GB-IE-KW-XD
7	1	330080-03	KABELSATZ (EURO)		NL
7	1	330080-03	KABELSATZ (EURO)		NO
7	1	330080-03	KABELSATZ (EURO)		SE
7	1	330080-03	KABELSATZ (EURO)		FR
7	1	330080-03	KABELSATZ (EURO)		GR
7	1	330080-03	KABELSATZ (EURO)		IT
7	1	330080-03	KABELSATZ (EURO)		DK
7	1	330080-03	KABELSATZ (EURO)		ES
7	1	330080-03	KABELSATZ (EURO)		FI
7	1	330080-03	KABELSATZ (EURO)		AT
7	1	330080-03	KABELSATZ (EURO)		BE
7	1	330080-03	KABELSATZ (EURO)		DE
7	1	330080-03	KABELSATZ (EURO)		B1
7	1	330080-03	KABELSATZ (EURO)		KR
7	1	330080-05	KABELSATZ		CH
7	1	330080-06	KABELSATZ		XE
7	1	573379-01	KABEL		AR
7	1	808704-12	KABELSATZ		TW
7	1	000000-00	NICHT MEHR LIEFERBAR		A9
8	1	369328	REGLER		
9	1	376010-01	ANTRIEB		TYPE 1A
9	1	376010-01	ANTRIEB		TYPE 1
10	1	748158	FEDER		
11	2	370966	UNTERLEGSCHIEBE		
12	2	847709	FEDER		
13	2	372523	KOHLE		
14	2	846076	KOHLEKASTEN		
15	1	811529	LITZE ZSB		KS635S - KS634S
15	1	811679	LITZE		KS638SE-EXCEPT TW
15	1	830393	LITZE		KS638SE-TW
16	1	372828	LITZE		KS638SE-TW
16	1	811504	LITZE		KS635S - KS634S



16	1	811666	LITZE	KS638SE-EXCEPT TW
17	2	828446	DROSSEL ZSB	XE
17	2	828446	DROSSEL ZSB	NL
17	2	828446	DROSSEL ZSB	NO
17	2	828446	DROSSEL ZSB	SE
17	2	828446	DROSSEL ZSB	FR
17	2	828446	DROSSEL ZSB	GR
17	2	828446	DROSSEL ZSB	IT
17	2	828446	DROSSEL ZSB	DK
17	2	828446	DROSSEL ZSB	ES
17	2	828446	DROSSEL ZSB	FI
17	2	828446	DROSSEL ZSB	AT
17	2	828446	DROSSEL ZSB	BE
17	2	828446	DROSSEL ZSB	DE
18	1	369620	MUTTER	
19	1	581229-01	GETR.GEH.	
20	1	369619	GETRIEBE	
21	6	891024	SCHRAUBE	
22	1	368389	ROLLER	
23	2	368360	KUGELLAGER	
24	1	571709-04	WELLE ZSB	
25	3	374292	STIFT	
26	1	799310	O-RING	
27	1	000000-00	NICHT MEHR LIEFERBAR	
28	1	000000-00	NICHT MEHR LIEFERBAR	
29	2	000000-00	NICHT MEHR LIEFERBAR	
30	1	368366	ABDECKUNG	
31	1	369008	SCHUTZ	
32	1	370584	SCHUTZ	
33	1	000000-00	NICHT MEHR LIEFERBAR	KS638SE
33	1	000000-00	NICHT MEHR LIEFERBAR	KS635S XE ONLY
33	1	000000-00	NICHT MEHR LIEFERBAR	KS634S
33	1	000000-00	NICHT MEHR LIEFERBAR	KS635S
34	1	368375-01	HALTERUNG ZSB	
35	1	368857-00	KLAMMER	
36	2	376409	SCHRAUBE	
37	1	369304-00	SCHUH ZSB	
39	1	581190-02	KLEMME ZSB	
40	1	370169	PLATTE	
41	2	370170	SPRENGRING	
42	1	571131-00	TEILEPAKET (SATZ)	
43	1	370168-01	ANTRIEB	
44	1	581190-02	KLEMME ZSB	
45	10	747329	SCHRAUBE	
46	1	749286	BUEGEL	
47	1	368355-03	KRAGEN	
48	1	376132	BLOCK	
49	1	368352-00	OBERER KNOPF	
50	1	371662	FEDER	
51	1	368353-00	UNTERER KNOPF	
52	1	371311	PLATTE	
53	1	811057	STIFT	



**COLOUR KEY**

ENGLISH	FRENCH	ITALIAN	GERMAN
BLACK	NOIR	NERO	SCHWARZ
GREY	GRIS	GRIGIO	GRAU
BROWN	BRUN	MARRONE	BRAUN
BLUE	BLEU	BLU	BLAU
RED	ROUGE	ROSSO	ROT