



STICHSÄGE

KS702PE---A

TYPE

1



Pos. Nr	Ersatzteilnummer	Beschreibung	Preis	Variants	QS
3	1	330080-03	KABELSATZ (EURO)		QS
3	1	589164-00	KABELSATZ		GB
4	1	148481-00	KABELTUELLE		
5	1	329301-00	KABELKLEMME		
6	1	90513109	SCHALTER		
7	2	90512961	SCHRAUBE		
8	1	90513112	KONDENSATOR		
9	1	90513113	ANKER ZSB		
10	1	90510498	LAGERBLOCK		
11	1	90510501	GABEL		
12	1	330041-07	STIFT		
13	1	90510500	FLIEHGEWICHT		
14	2	90510499	FUHRUNG		
15	1	90510503	GETRIEBE ZSB		
16	1	90512896	NADELLAGER		
17	1	582717-00	UNTERLEGSCHEIBE		
18	1	90510502	HALTER		
19	1	90510504	ANTRIEBSROLLE		
20	1	90513214	FELD ZSB 230V		
21	2	90510508	KOHLEKASTEN ZSB		
22	1	90512881	STOESSEL		
23	1	90510505	KUGELLAGER		
24	1	90510509	KUGELLAGER		
25	1	90510510	FILZDICHTUNG		
26	1	90515265	MESSERKLEMME		
27	2	797123	SCHRAUBE		
28	1	90513143	FLACHFEDER		
29	1	90513089	KAPPE		
30	1	90512994	FEDER		
31	1	90512880	HEBEL		
32	1	90512971	HALTER		
33	1	90513110	MESSERHALTERUNG ZSB		
34	1	90512892	STIFT		
35	1	90512893	NARBE		
36	1	90512889	DREHSTABFEDER		
37	1	330041-06	STIFT		
38	1	90512884	SCHUH		
39	1	90512886	PLATTE		
40	1	90512885	HALTER		
41	8	330019-03	SCHRAUBE		
42	2	330019-07	SCHRAUBE		
43	1	330019-00	SCHRAUBE		
44	1	368608	VAKUUMADAPTER		
45	1	90513704	TYPENSCHILD		
48	1	588384-00	ADAPTER ZSB		GB
49	2	90519315	SCHRAUBE		