



B021B



Ausgabe Issue 2001-1	Bild Nr. Picture No B021B	SWING 45	SWING 45	Seite Page 6
----------------------------	---------------------------------	----------	----------	--------------------

Pos. Fig.	Anzahl/Quantity				Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes

X	1	1			1117-3262-02	Chassie .....	Chassis .....		
	2	2			1117-3009-01	Radplatte .....	Wheel plate .....		
	3	2			1117-3010-01	Radplatte .....	Wheel plate .....		
	4	1			1117-3011-01	Radachse .....	Wheel axle .....		
	5	2			1111-3238-01	Rad .....	Wheel .....		
	6	2			1117-3225-02	Nabenkapsel-weiß .....	Hub cap-white .....		
	7	1			1117-3007-01	Leitschiene-vordere .....	Baffle-front .....		
	8	4			1117-3223-01	Ansatzbolzen .....	Shoulder bolt .....		
	9	2			1117-3224-02	Nabenkapsel-weiß .....	Hub cap-white .....		
	10	2			1117-1161-01	Radschutz .....	Wheel protection .....		
	11	1			1117-3008-01	Leitschiene-hintere .....	Baffle-rear .....		
	12	14			9836-9516-12	Schraube .....	Screw .....		
	13	1			1117-1156-02	Klappe-schwarz .....	Rear flap-black .....		
	14	1			1117-1143-01	Achse .....	Shaft .....		
	15	1			1117-1126-01	Feder .....	Spring-rear flap .....		
	16	1			1117-1155-02	Klapphalterung-schw. ....	Flap holder-black .....		
	17	1			1117-1135-02	Deckel-schwarz .....	Cover-black .....		
	18	1			9987-5251-12	Schraube .....	Screw .....		
	19	1			1117-1065-01	Tellerfeder .....	Spring washer .....		
	20	2			1111-3163-01	Rad .....	Wheel .....		
	21	8			1117-3012-01	Lagerbuchse .....	Wheel bush .....		
	22	4			1117-1364-01	Schraube .....	Screw .....		
	23	1			9600-0014-00	Keil .....	Key .....		
	24	1			1111-9703-01	Messer .....	Blade .....		
	25	4			1117-1131-01	Mutter .....	Nut .....		
	26	6			9699-0028-02	Scheibe .....	Flat washer .....		
	27	2			9898-0845-12	Schraube .....	Screw .....		
	28	1			1117-3030-01	Montagesatz .....	Assy kit .....		
	29	4			9579-0008-00	Kabelhalter .....	Cable holder .....		
	30	2			1117-3194-01	Verriegelungsrad .....	Locking knob .....		
	31	5			9799-0831-02	Mutter .....	Nut .....		
	32	1			1117-1149-01	Führungsholm-Untert. ....	Handle-lower part .....		
	33	1			1117-1221-01	Führungsholm-Obert. ....	Handle-upper part .....		
	34	1			1117-1355-01	Schlüssel .....	Socket wrench .....		
	35	1			1117-1134-01	Motorbremsdraht .....	Engine brake cable .....		
	35	1			1117-1183-01	Motorbremsdraht .....	Engine brake cable .....		
	36	1			1117-1157-02	Behälterdeckel-schwarz .....	Grassbag cover-black .....		
	37	1			1117-1218-01	Behälter-Unterteil .....	Lower grass bag .....		
	38	1			1117-1148-01	Deckel .....	Cap .....		
	39	1			9948-0640-16	Schraube .....	Screw .....		
	40	1			9699-0025-02	Scheibe .....	Washer .....		
	41	1			9595-0258-00	Spannstift .....	Locating pin .....		
	42	1			1111-9719-01	Messerhalterung .....	Blade holder .....		
	43	1			1117-3221-01	Regulierbügel .....	OPC lever .....		
	44	3			9997-0830-16	Schraube .....	Screw .....		
	45	3			9678-0009-02	Schloßscheibe .....	Lock washer .....		
	46	1			1111-2927-01	Batteriehalter .....	Battery holder .....		
	47	1			1117-1116-01	Schnurhalter .....	Ropeholder .....		
	48	1			9799-0631-02	Mutter .....	Nut .....		
	49	1			1117-1119-01	Propfen .....	Cap .....		

Vantage-Motor  
Classic-Motor  
Inkl. 17