





05004

Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung	Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung
001	94623-02001	Wellendichtring	005	94623-02005	O-Ring unten
002	94623-02002	O-Ring oben	006	94623-02006	Pumpenboden
003	94623-02003	Laufrad	007	94623-02007	Bodendeckel
004	94623-02004	Mutter			

