




94189





94189

Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung	Pos.-Nr.	Ersatzteil-Nr.	Bezeichnung
001	94189-03001	Lüfterrad	011	94189-03011	Mechanische Dichtung
002	94189-03002	Dichtung Schaltergehäuse	012	94189-03012	Flanscheinsatz
003	94189-03003	Schalter	013	94189-03013	O-Ring groß
004	94189-03004	Schaltergehäuse komplett	014	94189-03014	Laufgrad
005	94189-03005	Kondensator 30 μ F	015	94189-03015	Mutter
006	94189-03006	Motorgehäuse	016	94189-03016	Diffusor
007	94189-03007	Handgriff	017	94189-03017	O-Ring klein
008	94189-03008	Pumpenfuß	018	94189-03018	Pumpengehäuse
009	94189-03009	Flansch	019	94189-03019	Blindstopfen
010	94189-03010	Wellendichtring			

