


MODEL 461001x68A

REPAIR PARTS SEAT DECK




MODEL 461001x68A

REPAIR PARTS SEAT DECK

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	1001028	26	Link, PTO	094004Z
2	Support, Seat	094154E700	27	Shoulder, Bolt	009x39
3	Push-On Cap	028x23	28	Washer	017x57
4	Washer	017x47	29	Pin, Cotter	030x20
5	Bolt, Wing	1001054	30	Spring	166x39
6	Bolt	001x45	31	Bracket, PTO	094018E700
7	Bracket, Pivot	094153E700	32	Spring	166x40
8	Nut	15x123	33	Washer	17x103
9	Screw	26x229	34	Handle, Lift	690533Z
10	Spring, Leaf	094057	35	Grip	092697
11	Spring	164x31	36	Wheel, Steering	095185
12	Washer, Cup	094155 Z	37	Grip	091079
13	Bolt	009x55	38	Bellows	092059
14	Rod, Pivot	094156 Z	39	Rod, Parking Brake	1001271 Z
15	Bolt, Shoulder	009x56	40	Screw	26x267
16	Deck, Seat	1001286E700	41	Bearing, Lower	094124
17	Screw	26x263	42	Gear, Pinion	690183
18	Spring	164x30	43	E-Ring	011x25
19	Screw	26x249	44	Shaft, Steering	690626
20	Grip	092698	46	Pin, Cotter	0031x4
21	Handle, PTO	094217 Z	47	Nut	15x123
22	Screw	0025x3	48	Insert, Steering Wheel	711325
23	Paddle, Switch	094022 Z	49	Screw	0025x3
24	Lever, PTO	094017 Z	51	Washer	17x146
25	Nut	015x84	—	Manual and Parts List	F-020760L

MODEL 461001x68A

**REPAIR PARTS
HOOD AND DASH**




MODEL 461001x68A

**REPAIR PARTS
HOOD AND DASH**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Dash	094223	16	Lens, Left	092540
2	Screw	26x270	17	Brace, Grille	092541
3	Bearing, Upper Steering	094219	18	Rod, Pivot	093137 Z
4	Screw	26x239	19	Pin, Hair	0031x4
5	Panel, Side Access	093007E700	20	Container, Battery	690424
6	Channel, Support	095081	21	Plate, Lift Detent	094886E700
7	Screw	26x263	23	Nut	015x81
8	Screw	26x249	24	Mat, Left	094109
9	Support, Dash	095082	25	Support, Left Grille	690544E700
10	Plate, Dash	094221E700	26	Screw	26x277
12	Hood	093215E700	27	Support, Right Grille	690543E700
13	Bolt, Shoulder	009x47	28	Mat, Right	094108
14	Grille (Includes Lens)	092542	29	Deck, Seat	1001286E700
15	Lens, Right	092539			

MODEL 461001x68A

REPAIR PARTS MOTION DRIVE



MODEL 461001x68A

REPAIR PARTS MOTION DRIVE


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Lever, Shift	690366Z	30	Wheel and Tire	093263-601
2	Grip	092697	31	Tire *	091923
3	Plate, Adjusting	690131 Z	—	Tube	407049
4	Nut	015x88	32	Latch, Parking Brake	094045 Z
5	Washer	17x103	33	Pedal	021544
6	Link, Shift	690130 Z	34	Belt, Drive	037x68
8	Spring, Extension	165x116	35	Yoke, Shift	690129 Z
9	Stud, Spring	094042 Z	36	Washer, Square	17x148
10	Nut	015x79	37	Pilot, Support	091889
11	Bolt, Shoulder	009x39	38	Washer	017x38
12	Nut	015x89	39	Capscrew	06x105
13	Rod, Clutch	094041 Z	40	Pin, Hair	0031x6
14	Arm Assembly, Idler	690364 Z	41	Spacer, Left	690213 Z
15	Bolt, Shoulder	009x54	42	Washer	17x118 Z
16	Nut, Adjusting	094815	43	Pin, Cotter	030x20
17	Screw	26x249	44	Pulley, V Idler	690410
18	Bracket, Spring Mount	690070E700	45	Pulley, Backside Idler	023339
19	Bolt	01x155	46	Washer	17x169
20	Bolt, Carriage	002x78	47	Spring, Brake	165x115
21	Bolt, Carriage	002x53	48	Ring, Snap	0011x7
22	Bolt	26x216	49	Pulley, Drive	690181
23	Bracket, Left Torque	690081E700	50	Bracket, Right Torque	690080E700
24	Nut	015x84	51	Spring, Extension	165x92
25	Pin, Hair	0031x4	52	Transmission †	—
26	Cap, Hub	094618	53	Key, Square	024039
27	E-Ring	011x23	54	Spacer, Right	690214 Z
28	Washer	17x193	55	Spring, Extension	165x133
29	Stem, Valve	024373	56	Spacer	690369

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† For information on Replacement Parts see the Central Parts Distributor in your area.

MODEL 461001x68A


**REPAIR PARTS
SECTOR GEAR**



Key No.	Description	Part No.
1	Bolt, Shoulder	009x62
2	Nut, Lock	15x111
3	Nut, Flange	015x79
4	Guide, Screw	094384
5	Link, Left Drag	690146E700
6	Washer	17x168
7	Nut, Flange	015x84
8	Link, Right Drag	690145E700
9	Bolt	001x84
10	Bearing, Sector Gear	690180
11	Fitting, Lub	092530
12	Gear, Sector	690147E700
13	Plate, Steering	1001121E700

MODEL 461001x68A


**REPAIR PARTS
FRONT AXLE**



Key No.	Description	Part No.	Key No.	Description	Part No.
1	Bracket, Rear Hanger	690067E700	8	Hanger, Left Deck	690198E700
2	Nut, Flange	15x118	9	Screw	26x249
3	Axle Assembly (with fitting)	1001460E700	10	Bolt	01x146
4	Pin, Hair	030x49	11	Spindle Assembly, Left	690179E700
5	Washer	017x75	12	Hanger, Axle	094007E700
6	Bearing, Spindle	093058	13	Hanger, Right Deck	690199E700
7	Fitting, Lub	092530	14	Spindle Assembly, Right	690178E700

MODEL 461001x68A

**REPAIR PARTS
FRONT FRAME ASSEMBLY**




Key No.	Description	Part No.	Key No.	Description	Part No.
1	Frame, Right	1001268E700	15	Washer	17x152
2	Frame, Left	1001269E700	16	Nut	015x41
3	Nut, Flange	015x84	17	Screw	025x15
4	Stud, Swivel	690182	18	Guide, Belt	690192E700
5	Bracket Assembly, Suspension	690406E700	19	Assembly, Steering †	†
6	Pin, Cotter	030x20	20	Wheel & Tire Assembly	092644-601
7	Screw	26x249	21	Tire *	024393
8	Plate, Engine	094006E700	—	Tube	407049
9	Nut	015x88	—	Bearing, Wheel	093604
10	Bracket, PTO Crank	094005E700	22	Stem, Valve	024373
11	Bolt, Carriage	002x87	23	Washer	17x194
12	Washer	017x57	24	Washer	17x114
13	Crank, PTO	690394E700	25	Pin, Cotter	030x49
14	Lever, Brake/Clutch	094038E700	26	Cap, Hub	094618

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† See the Sector Gear Repair Parts page.

MODEL 461001x68A

**REPAIR PARTS
REAR FRAME ASSEMBLY**




Key No.	Description	Part No.
1	Frame, Rear Hitch	690094E700
2	Bracket, Seat Deck	690077E700
3	Screw	26x249
4	Nut, Flange	015x84
5	Washer	17x168
6	Link, Lift Handle	690122E700
7	Pin, Hair	0031x4
8	Assembly, Lifter	1001111E700
9	Bracket, Left Transaxle	690065E700
10	Bracket, Lift Pivot	094015E700
11	Bolt, Shoulder	009x53

Key No.	Description	Part No.
13	Spacer, Lifter	690151
14	Bolt, Carriage	002x85
15	Nut, Flange	015x79
16	Bracket, Right Shift	1001302E700
17	Screw, Guide	094384
18	Plate	690482E701
19	Bracket, Right Transaxle	690064E700
20	Frame, Right	1001268E701
21	Frame, Left	1001269E701
22	Bracket, Idler	690365 Z
23	Plate, Stiffening	1001098E700

MODEL 461001x68A

REPAIR PARTS ENGINE MOUNT ASSEMBLY



MODEL 461001x68A


REPAIR PARTS ENGINE MOUNT ASSEMBLY

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Cap, Fuel	1001279	22	Pulley, Stack	690225
2	Tank, Fuel	093148	23	Washer	17x170
6	Screw	26x263	24	Lockwasher	019x35
7	Assembly, Right Grille Support	690546E700	25	Bolt	01x140
8	Shield, Heat	690535	26	Gasket	711851
9	Assembly, Left Grille Support	690547E700	27	Washer	018x15
10	Shield, Heat	095090	28	Bolt	001x91
11	Screw	26x290	29	Tube, Right Exhaust	690541
12	Guard	690540	30	Tube, Left Exhaust	690542
13	Shield, Lower	094958	31	Bracket, Muffler Mounting	690537
14	Engine *	*	32	Muffler	093259
15	Line, Fuel (17 inches long)	690333	33	Bracket, Muffler	690538
16	Clamp	095197	34	Choke	690401
18	Pipe, Oil Drain	092279	35	Nut	015x68
19	Cap, Oil Drain	021651	36	Screw	26x201
20	Bolt	0025x7	37	Control, Throttle	093165
21	Spacer	093077			

* Parts are available from an Engine Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.


MODEL 461001x68A

REPAIR PARTS ELECTRICAL SYSTEM



MODEL 461001x68A


**REPAIR PARTS
ELECTRICAL SYSTEM**



Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	92372
	Bulb, Light	90084
2	Harness, Chassis Wire	250x87
3	Switch, Ignition	92556
	Key, Ignition	20729
	Nut, Hex	91489
	Cap, Ignition	91488
4	Switch, Limit	94136
5	Fuse	54212
	Holder, Fuse	407078
6	Solenoid	94613
	Screw, Mounting	26x229
	Locknut	15x116
7	Cable, Battery Ground	24x32
	Screw, Ground Cable	26x213
8	Battery	21075
	Bolt, Carriage	2x82
	Wingnut	14x79
9	Harness, Seat Switch Wire	250x67
10	Switch, Seat Sensor	94159
11	Cable	24x31
12	Ammeter	093156


MODEL 461001x68A

**REPAIR PARTS
MOWER HOUSING SUSPENSION**



MODEL 461001x68A


**REPAIR PARTS
MOWER HOUSING SUSPENSION**



Key No.	Description	Part No.
1	Knob	094068
2	Washer	017x45
3	Pad, Friction	094137
5	Pin, Hanger	095194
6	Link, Lift	690550E700
7	Nut, Flange	015x84
8	Bolt, Shoulder	009x52
9	Bracket, Rear Suspension	690578E700
10	Bolt, Gauge Wheel	094025
11	Wheel	092683
12	Pin, Hair	031x11
13	Washer	017x91
14	Washer	17x103
15	Pin, Cotter	030x49
16	Rod, Deflector	092159 Z
17	Push-On Cap	028x23
18	Roller	1001252
20	Rod, Deck Suspension	094996
21	Pin, Hair	0031x4
22	Screw	26x249
23	Bracket, Front Suspension	094765E700
24	Rod, Hanger	094158 Z
25	Stiffener	094604E700
26	Spring	166x34
27	Deflector, Inside	092103E700
28	Deflector, Chute	092100

MODEL 461001x68A

REPAIR PARTS BLADE DRIVE




MODEL 461001x68A

REPAIR PARTS BLADE DRIVE

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Pulley	094592	24	Bracket, Brake Plate	094602E700
2	Nut	15x121	25	Screw	26x249
3	Nut	015x98	26	Brake Assembly, Left	094640E700
4	Belt, Secondary	037x66	27	Plate, Brake Arm	094596E700
5	Belt, Primary	037x96	28	Brake Assembly, Center	094641E700
6	Pulley, Idler	690387	29	Nut, Flange	015x79
8	Spacer, Pulley	1001197	30	Spring	165x79
9	Pulley, Idler	690549	31	Bracket, Cover	092140E700
10	Link, Bell Crank	094606 Z	32	Bell Crank	094603E700
11	Spring	166x41	33	Guide, Belt	092116 Z
12	Spring	165x138	34	Bracket, Pulley Cover	690221E700
13	Screw	26x270	35	Guide, Belt	091754
14	Cover, Right Pulley	094607E700	36	Assembly, Jackshaft Housing	1001200
15	Bolt, Shoulder	009x39	37	Washer	17x166
16	Arm Assembly, Idler	094639E700	38	Washer	17x165
18	Washer	017x47	39	Nut, Blade	15x100
19	Screw	26x277	40	Blade	1001508E701
20	Cover, Left Pulley	094645E700	41	Adapter, Blade	690411
21	Arm Assembly, Idler	690579E700	42	Bolt, Carriage	002x53
22	Bolt	0025x7	43	Spacer	690369
23	Pin, Cotter	030x20			

MODEL 461001x68A

**REPAIR PARTS
MOWER HOUSING**



Key No.	Description	Part No.	Key No.	Description	Part No.
1	Bolt, Shoulder	009x51	11	Bracket, Left Gauge Wheel	094919E700
2	Plate, Suspension	690128E700	12	Bolt, Carriage	002x53
3	Bracket, Right Rear	094598E700	13	Housing, Blade	690204E700
4	Bracket, Hinge	092104E700	14	Bracket, Front Deck	094997SE
5	Spring, Left	166x43	15	Bracket, Right Gauge Wheel	094918E700
6	Nut, Flange	015x79	16	Retainer	028x64
7	Nut, Flange	015x84	17	Bolt, Carriage	002x74
8	Bracket, Bell Crank	094601E700	18	Spring, Right	166x42
9	Nut, Flange	015x88	—	Complete Mower Housing	776111
10	Bracket, Left Lifter	094600E700			