


MODEL 461005x68A

REPAIR PARTS SEAT DECK




MODEL 461005x68A

REPAIR PARTS SEAT DECK

Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001028	Seat	27	009x39	Shoulder, Bolt
2	094154E701	Support, Seat	28	017x57	Washer
3	028x23	Push-On Cap	29	030x20	Pin, Cotter
4	017x47	Washer	30	166x39	Spring
5	1001054	Bolt, Wing	31	094018E701	Bracket, PTO
6	001x45	Bolt	32	166x40	Spring
7	1001648E701	Bracket, Pivot	33	17x103	Washer
8	15x123	Nut	34	690533 Z	Handle, Lift
9	26x229	Screw	35	092697	Grip
10	094057	Spring, Leaf	36	095185	Wheel, Steering
11	164x31	Spring	37	091079	Grip
12	094155 Z	Washer, Cup	38	092059	Bellows
13	009x55	Bolt	39	1001245 Z	Rod, Parking Brake
14	094156 Z	Rod, Pivot	40	26x267	Screw
15	009x56	Bolt, Shoulder	41	094124	Bearing, Lower
16	1001555E700	Deck, Seat	42	690183	Gear, Pinion
17	26x263	Screw	43	011x25	E-Ring
18	164x30	Spring	44	690625	Shaft, Steering
19	26x249	Screw	46	0031x4	Pin, Cotter
20	092698	Grip	47	15x123	Nut
21	094017 Z	Handle, PTO	48	711326	Insert, Steering Wheel
22	0025x3	Screw	49	0025x3	Screw
23	094022 Z	Paddle, Switch	51	17x146	Washer
24	094826 Z	Lever, PTO	70	1001542	Holder, Cup
25	015x84	Nut	—	1001511	Bag, Parts
26	094004 Z	Link, PTO	—	F-040728L	Manual and Parts List

MODEL 461005x68A

REPAIR PARTS HOOD AND DASH




MODEL 461005x68A

REPAIR PARTS HOOD AND DASH

Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001593E701	Dash	28	1001550	Housing, Left Headlamp
2	26x201	Screw	29	1001551	Lens, Right
3	1001491	Bearing, Upper Steering	30	1001549	Housing, Right Headlamp
4	26x238	Screw	31	26x270	Screw
5	093007E701	Panel, Side Access	41	009x58	Bolt
8	26x249	Screw	42	1001456E701	Shield, Heat
9	095318E701	Support, Dash	49	26x277	Screw
11	095408	Mat, Left	51	15x124	Nut
12	095409	Mat, Right	53	1001540	Insert, Grille
20	690424	Container, Battery	55	0193x1	Fastener, Panel
21	094886E701	Plate, Lift Detent	57	1001652	Trim, Hood (3.75")
23	015x81	Nut	58	1001653	Trim, Hood (6.5")
25	1001537E700	Hood	59	1001755	Grommet, Parking Brake
26	1001533E701	Grille	70	1001542	Holder, Cup
27	1001552	Lens, Left			

MODEL 461005x68A

REPAIR PARTS MOTION DRIVE



F-040728L

MODEL 461005x68A

REPAIR PARTS MOTION DRIVE


Key No.	Part No.	Description	Key No.	Part No.	Description
1	690366 Z	Lever, Shift	31	091923	Tire *
2	092697	Grip	—	407049	Tube
3	690131 Z	Plate, Adjusting	32	094045 Z	Latch, Parking Brake
4	015x88	Nut	33	021544	Pedal
5	17x103	Washer	34	037x68	Belt, Drive
6	690130 Z	Link, Shift	35	690129 Z	Yoke, Shift
8	165x116	Spring, Extension	36	17x148	Washer, Square
9	094042 Z	Stud, Spring	37	091889	Pilot, Support
10	015x79	Nut	38	017x38	Washer
11	009x39	Bolt, Shoulder	39	06x105	Capscrew
12	015x89	Nut	40	0031x6	Pin, Hair
13	094041 Z	Rod, Clutch	41	690213 Z	Spacer, Left
14	690364 Z	Arm Assembly, Idler	42	17x118 Z	Washer
15	009x54	Bolt, Shoulder	43	030x20	Pin, Cotter
16	094815 Z	Nut, Adjusting	44	690410	Pulley, V Idler
17	26x249	Screw	45	023339	Pulley, Backside Idler
18	690070E700	Bracket, Spring Mount	46	17x169	Washer
19	01x155	Bolt	47	165x115	Spring, Brake
20	002x78	Bolt, Carriage	48	0011x7	Ring, Retainer
21	002x53	Bolt, Carriage	49	690181	Pulley, Drive
22	26x216	Bolt	50	690080E700	Bracket, Right Torque
23	690081E700	Bracket, Left Torque	51	165x92	Spring, Extension
24	015x84	Nut	52	— † —	Transmission, Peerless
25	0031x4	Pin, Hair	53	024039	Key, Square
26	094618	Cap, Hub	54	690214 Z	Spacer, Right
27	011x23	E-Ring	55	165x133	Spring, Extension
28	17x193	Washer	56	690369	Spacer
29	024373	Stem, Valve	57	015x98	Nut, Flange Lock
30	093263-601	Wheel and Tire			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† For Replacement Parts for this transaxle contact the manufacturer.

MODEL 461005x68A


REPAIR PARTS
SECTOR GEAR



Key No.	Part No.	Description
1	009x62	Bolt, Shoulder
2	15x111	Nut, Lock
3	015x79	Nut, Flange
4	094384	Guide, Screw
5	690146E700	Link, Left Drag
6	17x168	Washer
7	015x84	Nut, Flange
8	690145E700	Link, Right Drag
9	001x84	Bolt
10	690180	Bearing, Sector Gear
11	092530	Fitting, Lub
12	690147	Gear, Sector
13	1001121E701	Plate, Steering

MODEL 461005x68A

**REPAIR PARTS
FRONT AXLE**




Key No.	Part No.	Description
1	690067E700	Bracket, Rear Hanger
2	15x118	Nut, Flange
3	1001460E701	Axle Assembly (with fitting)
4	030x49	Pin, Hair
5	017x75	Washer
6	093058	Bearing, Spindle
7	092530	Fitting, Lub

Key No.	Part No.	Description
8	690198E701	Hanger, Left Deck
9	26x249	Screw
10	01x146	Bolt
11	690179E701	Spindle Assembly, Left
12	094007E701	Hanger, Axle
13	690199E701	Hanger, Right Deck
14	690178E701	Spindle Assembly, Right

MODEL 461005x68A

REPAIR PARTS FRONT FRAME ASSEMBLY




Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001928E701	Frame, Right	15	17x152	Washer
2	1001927E701	Frame, Left	16	015x41	Nut
3	015x84	Nut, Flange	17	025x15	Screw
4	690182	Stud, Swivel	18	690192E701	Guide, Belt
5	690406E700	Bracket Assembly, Suspension	19	†	Assembly, Steering
6	030x20	Pin, Cotter	20	092644-601	Wheel & Tire Assembly
7	26x249	Screw	21	024393	Tire *
8	094006E701	Plate, Engine	—	407049	Tube
9	015x88	Nut	—	093604	Bearing, Wheel
10	094005E700	Bracket, PTO Crank	22	024373	Stem, Valve
11	002x87	Bolt, Carriage	23	17x194	Washer
12	017x57	Washer	24	17x114	Washer
13	690394E701	Crank, PTO	25	030x49	Pin, Cotter
14	094038E700	Lever, Brake/Clutch	26	094618	Cap, Hub

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† See the Sector Gear Repair Parts page.

MODEL 461005x68A

**REPAIR PARTS
REAR FRAME ASSEMBLY**




Key No.	Part No.	Description
1	690094E701	Frame, Rear Hitch
2	690077E701	Bracket, Seat Deck
3	26x249	Screw
4	015x84	Nut, Flange
5	17x168	Washer
6	690122E700	Link, Lift Handle
7	0031x4	Pin, Hair
8	1001111E701	Assembly, Lifter
9	1001917E700	Bracket, Left Transaxle
10	094015E701	Bracket, Lift Pivot
11	009x53	Bolt, Shoulder

Key No.	Part No.	Description
13	690151	Spacer, Lifter
14	002x85	Bolt, Carriage
15	015x79	Nut, Flange
16	1001302E701	Bracket, Right Shift
17	094384	Screw, Guide
18	690482E701	Bracket, Battery Support
19	690064E700	Bracket, Right Transaxle
20	1001928E701	Frame, Right
21	1001927E701	Frame, Left
22	690365 Z	Bracket, Idler
23	1001098E701	Plate, Stiffening

MODEL 461005x68A

REPAIR PARTS ENGINE MOUNT ASSEMBLY



MODEL 461005x68A

REPAIR PARTS ENGINE MOUNT ASSEMBLY


Key No.	Part No.	Description	Key No.	Part No.	Description
1	092317	Cap, Fuel **	26	711851	Gasket
2	690289	Tank, Fuel	28	06x103	Bolt
3	26x253	Screw	29	690541	Tube, Right Exhaust
6	26x229	Screw	30	690542	Tube, Left Exhaust
7	26x263	Screw	31	690537E701	Bracket, Muffler Mounting
13	--- * ---	Engine, Briggs & Stratton	32	093259	Muffler
14	7601033	Line, Fuel (18 inches long) **	33	690538E700	Bracket, Muffler
15	095197	Clamp **	34	690401	Choke
18	325547	Valve, Oil Drain	35	015x68	Nut
19	327422	Cap, Oil Drain	36	26x201	Screw
20	0025x7	Bolt	37	093165	Control, Throttle
21	093077	Spacer	38	1001456E701	Shield Assembly, Heat
22	690225	Pulley, Stack	39	1001588	Plenum
23	17x170	Washer	40	1001620E701	Guard, Heat Shield
24	019x35	Lockwasher	41	028x44	Speed Nut
25	01x140	Bolt	43	26x277	Screw

* For information on Replacement Parts for this engine contact the manufacturer.

** These parts are included with Key number 2.


MODEL 461005x68A

REPAIR PARTS
ELECTRICAL SYSTEM



MODEL 461005x68A


REPAIR PARTS ELECTRICAL SYSTEM



Key No.	Part No.	Description
1	250x92	Harness, Light Wire
	1001716	Socket, Light
	090084	Bulb, Light
2	250x112	Harness, Chassis Wire
3	092556	Switch, Ignition
	020729	Key, Ignition
	091489	Nut, Hex
	091488	Cap, Ignition
4	1001575	Switch, Limit
5	302031	Fuse
	407078	Holder, Fuse
6	094613	Solenoid
	26x229	Screw, Mounting
	15x116	Locknut
7	024x32	Cable, Battery Ground
	26x229	Screw, Ground Cable
8	021075	Battery
	002x82	Bolt, Carriage
	014x79	Wingnut
	054148	Boot, Battery Terminal –Positive
9	250x67	Harness, Seat Switch Wire
10	094159	Switch, Seat Sensor
11	024x31	Cable


MODEL 461005x68A

REPAIR PARTS
MOWER HOUSING SUSPENSION



MODEL 461005x68A


**REPAIR PARTS
MOWER HOUSING SUSPENSION**



Key No.	Part No.	Description
1	094068	Knob
2	017x45	Washer
3	094137	Pad, Friction
5	095194	Pin, Hanger
6	690550E700	Link, Lift
7	015x84	Nut, Flange
8	009x52	Bolt, Shoulder
9	690578E700	Bracket, Rear Suspension
10	094025	Bolt, Gauge Wheel
11	092683	Wheel
12	031x11	Pin, Hair
13	017x91	Washer
14	17x103	Washer
15	030x49	Pin, Cotter
16	092159 Z	Rod, Deflector
17	028x23	Push-On Cap
18	1001252	Roller
20	094996	Rod, Deck Suspension
21	0031x4	Pin, Hair
22	26x249	Screw
23	094765E700	Bracket, Front Suspension
24	094158 Z	Rod, Hanger
25	094604E700	Stiffener
26	166x34	Spring
27	092103E700	Deflector, Inside
28	092100	Deflector, Chute

MODEL 461005x68A

REPAIR PARTS BLADE DRIVE



MODEL 461005x68A


REPAIR PARTS BLADE DRIVE

Key No.	Part No.	Description	Key No.	Part No.	Description
1	094592	Pulley	25	26x249	Screw
2	15x140	Nut	27	094596E700	Plate, Brake Arm
3	015x98	Nut	29	015x79	Nut, Flange
4	037x66	Belt, Secondary	30	165x79	Spring
5	037x96	Belt, Primary	31	092140E701	Bracket, Cover
6	690387	Pulley, Idler	33	092116 Z	Guide, Belt
8	1001197	Spacer, Pulley *	34	690221E701	Bracket, Pulley Cover
9	690549	Pulley, Idler	35	091754 Z	Guide, Belt
12	165x138	Spring	36	1001200	Ass'y, Jackshaft Housing
13	26x270	Screw	37	17x166	Washer
14	094607E701	Cover, Right Pulley	38	17x165	Washer
15	009x39	Bolt, Shoulder	39	15x100	Nut, Blade
16	094639E701	Arm Assembly, Idler	40	1001508E701	Blade
19	26x277	Screw	41	690411	Adapter, Blade
20	094645E701	Cover, Left Pulley	42	002x53	Bolt, Carriage
21	690579E700	Arm Assembly, Idler	43	690369	Spacer
22	0025x7	Bolt			
24	094602E701	Bracket, Brake Plate			

* This is included with Key number 36.

MODEL 461005x68A

**REPAIR PARTS
MOWER HOUSING**



Key No.	Part No.	Description	Key No.	Part No.	Description
1	009x51	Bolt, Shoulder	11	094919E700	Bracket, Left Gauge Wheel
2	690128E700	Plate, Suspension	12	002x53	Bolt, Carriage
3	094598E700	Bracket, Right Rear	13	690204E700	Housing, Blade
4	092104E700	Bracket, Hinge	14	094997SE	Bracket, Front Deck
5	166x43	Spring, Left	15	094918E700	Bracket, Right Gauge Wheel
6	015x79	Nut, Flange	16	028x64	Retainer
7	015x84	Nut, Flange	17	002x74	Bolt, Carriage
8	094601E700	Bracket, Bell Crank	18	166x42	Spring, Right
9	015x88	Nut, Flange	—	776111	Complete Mower Housing
10	094600E700	Bracket, Left Lifter			