



204310x78A



204310x78A

1	Housing	776150	24	Rod, Pivot **	215x17 Z
2	Engine *	*	25	Door, Rear	672610
3	Bolt, Carriage	00x81	26	Spring **	166x44
4	Adjuster, Left Rear Height	672605	27	Guard, Rear	671970
5	Push Retainer **	028x49	28	Wheel	672060
6	Bracket, Left Handle	1101239E700	29	Bracket, Right Handle	1101238E700
7	Adjuster, Left Front Height	672601	30	Adjuster, Right Rear Height	672604
8	Nut, Flange	015x68	31	Screw	26x245
9	Nut, Hex	15x102	51	Bolt, Carriage	002x16
10	Washer	017x38	52	Screw	26x221
11	Screw	004x21	53	Push On Cap	028x42
13	Nut, Flange	015x84	66	Wingnut	071495
14	Washer, Belleville	17x137	67	Retainer, Push	028x64
15	Washer	17x124	68	Bezel	671926
16	Bolt	01x153	69	Pin, Pivot	215x18 Z
17	Blade	672763E701	70	Deflector, Chute	671927
18	Adapter, Blade	672503	74	Knob	071495
19	Adjuster, Right Front Height	672600	—	Instruction Book	F-020466L
20	Bolt, Engine	0025x6	** These parts are included with Key 25.		
23	Nut, Flange	015x88			

204310x78A



1	Handle, Upper (Black)	1101555E701	13	Engine Stop Lever	671924E701
2	Handle, Lower (Black)	672874E701	14	Bracket, Stop Lever	1101454
3	Bolt	002x77	15	Fastener, Cable	1101353
4	Knob, Plastic	071294	16	Engine Stop Cable	1101362
7	Locknut	15x116	21	Frame, Top	071592
12	Guide, Rope	071530	22	Frame Assembly	672905
			23	Bag, Cloth	1101030