

931 - Starter kpl.





Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
3		093500397	Starter griff	
4		4098073R	Starterseil	
7		004000132R	Feder	
8		094000033A	Seilrolle	
13		004000436R	Stift	
14		004000140	Sperrklinke	
18		005000361	Scheibe	
22		50030112	Feder	
26		50030155R	Kabel	
27		50030151R	Schalter	
28		50030143	Schwungrad	
29		50030156R	Kabel	
30		3833080	Scheibe	
31		004000142	Mutter	
32		50030087R	Schraube	
33		50030161	Flansch	
34		094600041R	Schraube	
35		094500034R	Scheibe	
36		50030148R	Kerzenstecker	
37		50030149R	Feder	
38		50030147R	Zündkerze	
39		50030158R	Gehäuse	
40		50030145R	Distanzstück	
41		50030064R	Schraube	
42		50030157R	Gehäuse	
43		50030146R	Schraube	
44		50030142R	Zündspule	
45		50030160R	Buchse	
46		50030150R	Mantel	



931 - Motor





Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
25		50030021R	Schraube	
26		50030003R	Motorgehäuse	
27		50030004R	Schraube	
28		50030013R	Kobelnring	
29		50030014R	Ring	
30		50030012R	Lager	
31		50030011R	Kurbelwelle	
32		50030015R	Kobelnring	
33		50030010R	Scheibe	
34		50030009R	Lager	
35		50030008R	Ring	
36		50030007R	Kolben ring	
37		50030006R	Kolbenring	
38		50030002R	Zylinder	
39		50030020	Dichtung	
40		50030016R	Auspuff	
41		50030147R	Zündkerze	
42		50032010	Kolben kpl. Ø37	
43		50032008	Dichtungen set	



931 - Kupplung






Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
27		50030138R	Mitnehmer	
28		50030089	Lager	
29		50032009	Ritzel	
30		50030092	Scheibe	
31		50030093	Feder	
32		50030090	Kupplung	
33		50030095R	Kettenradschutz	
34		50030099	Schultz	
35		50030100	Feder	
36		3914003	Mutter	
37		3916005	Scheibe	
38		50030105R	Distanzstück	
39		50030101R	Schraube	
40		50030110	Feder	
41		50030106R	Buchse	
42		50030107R	Hebel	
43		50030122	Deckel	
44		50030087R	Schraube	
45		50030116R	Stift	
46		50030118R	Hebel	
47		50030111	Feder	
48		50030117	Stift	
49		50030119R	Bremsband	
50		50030113R	Hebel	
51		094500155	Mutter	
52		50030121	Feder	



931 - Luftfilter und vergaser





Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
10		004000025	Dichtung	
13		50030023	Dichtung	
14		50030056	Dichtung	
15		50030177R	Buchse	
16		50030176R	Starterhebel	
17		2318610R	Vergaser WT-477A	
18		50030167R	Starterhebel	
19		50030166R	Distanzstück	
20		50030022R	Ventil	
25		50030168R	Schraube	
26		50030181R	Knopf	
27		50030184R	Ring	
28		50030179R	Deckel	
29		50030185R	Luft filter	
30		50030188R	Luft filter	
31		50032008	Dichtungen set	





931 - Handgriff






Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
12		50030064R	Schraube	
13		50030086R	Schraube	
14		50030083	Deckel	
15		50030082AR	Gashebel	
16		50030077	Feder	
17		50030076R	Stift	
18		50030078R	Schalter	
19		50030074	Handgriff	
20		50030081	Stift	
21		50032012	Hebel kpl.	
22		50030080	Feder	
23		50030065R	Handgriff	
24		50030071R	Schraube	
25		50030068	Band	
26		50030067R	Halter	
27		50030073R	Schraube	



931 - Vergaser


per }  
for } mod. 931



**16** ■ KIT RIPARAZIONE  
REPAIR KIT

**22** ● KIT MEMBRANE & GUARNIZIONI  
DIAPHRAGM & GASKET SET

Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
1		2318616	Feder	
2		2318617	Schraube	
3		375100078	Klappe	
4		003300209	Schraube	
5		2318615	Feder	
6		2318611	Welle	
7		035000165	Feder	
8		2318618	Schraube L	
9		2318619	Schraube H	
10		093500115	Feder	
11		035000162	Schraube	
12		2318191	Deckel	
13		003300202	Schraube	
14		003300201	Bissel	
15		2318613	Duese	
16		094600209	Reparatur-satz	
17		2318614	Hebel	
18		095000164	Kranz	
19		003300036	Anschluss	
20		2318612	Deckel	
21		003300197	Schraube	
22		094600210	Vergaser satz	
23		2318610R	Vergaser WT-477A	



931 - Tank




Bild Nr.	Anz.	Teilenummer	Beschreibung	Technische Nachricht
1		50030040R	Ventiltank	
2		50030039R	Buchse	
3		50030038R	Anschluss	
4		50030037R	Schelle	
5		50030035R	Rohr	
6		50030236R	Buchse	
7		50030036R	Benzinfilter	
8		50032011	Kettespannschraube	
9		50030125	Blech	
10		50030063R	Deckel	
11		50030071R	Schraube	
12		50030127R	Schultz	
13		50030052R	Sicherung	
14		50030024R	Kurbelgehäuse	
15		50030064R	Schraube	
16		50030140R	Deckel	
17		50030139	Dichtung	
18		50030137R	Schraube	
19		50030129	Oelpumpe	
20		50030136R	Schraube	
21		50030047R	Schlauch	
22		50030048R	Oelfilter	
23		50030046R	Buchse	
24		50030173R	Buchse	
25		50030044R	Oelfilter	
26		50030087R	Schraube	
27		50030229R	Halter	
28		50030053R	Ventiltank	
29		50030085R	Halter	
30		50030178R	Stopfen	
31		50030175R	Flansch	
32		50030174R	Flansch	
33		50030033R	Ventiltank	
34		50030374R	Schraube	
35		50030061R	Dichtung	
36		50030059R	Stopfen	
37		50030172R	Stange	
38		50030057R	Deckel	